



# **BenQ DX/S660 DX/S650**

---

## **User's Guide**

## Copyright

---

Copyright © 2002 by BENQ Corporation (formerly Acer Communications & Multimedia Inc.). All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of BENQ Corporation.

## Disclaimer

---

BENQ Corporation makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Furthermore, BENQ Corporation reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation of BENQ Corporation to notify any person of such revision or changes.

| Fill this in!!                                                                                                                    |                      |
|-----------------------------------------------------------------------------------------------------------------------------------|----------------------|
| In case service is needed in the future, record the information described below. The serial number is on the back of the product. |                      |
| <b>Projector Information</b>                                                                                                      |                      |
| Product Name:                                                                                                                     | DX/S660      DX/S650 |
| Serial Number:                                                                                                                    |                      |
| Date of Purchase:                                                                                                                 |                      |
| <b>Dealer Information</b>                                                                                                         |                      |
| Dealer:                                                                                                                           |                      |
| Telephone Number:                                                                                                                 |                      |
| Address:                                                                                                                          |                      |



# Table of Contents

|                                                             |           |
|-------------------------------------------------------------|-----------|
| <b>Introduction</b>                                         | <b>I</b>  |
| Safety Instructions                                         | I         |
| Warranty                                                    | 2         |
| Limited Warranty                                            | 2         |
| Shipping Contents                                           | 3         |
| Optional Accessories                                        | 3         |
| Projector Description                                       | 4         |
| Projector                                                   | 4         |
| External Control Panel                                      | 5         |
| Adjuster                                                    | 6         |
| Projector Features                                          | 6         |
| Remote Control Description                                  | 7         |
| Installing or Replacing Batteries                           | 8         |
| <b>Installation</b>                                         | <b>9</b>  |
| Screen Size                                                 | 9         |
| Connecting to Various Equipment                             | 9         |
| <b>Operation</b>                                            | <b>II</b> |
| Start Up                                                    | II        |
| Digital Keystone Correction                                 | 12        |
| Auto Adjustment                                             | 12        |
| Source Selection                                            | 13        |
| Menu System                                                 | 13        |
| 1. Display Menu                                             | 14        |
| 2. Image Menu                                               | 15        |
| 3. Source Menu                                              | 16        |
| 4. Control Menu                                             | 17        |
| 5. PIP Menu                                                 | 18        |
| Shutdown                                                    | 19        |
| <b>Maintenance</b>                                          | <b>20</b> |
| Lamp Information                                            | 20        |
| Use and Replacement of the Lamp                             | 20        |
| Lamp LED Indicators                                         | 20        |
| Lamp Replacement                                            | 21        |
| Resetting Lamp Hours                                        | 22        |
| Temp Information                                            | 22        |
| Service Information                                         | 23        |
| Accessories (included in the Standard Package)              | 23        |
| Optional Accessories (not included in the Standard Package) | 23        |
| Ordering Parts or Getting Information                       | 23        |
| <b>Troubleshooting</b>                                      | <b>24</b> |
| Status Messages                                             | 25        |

**Specifications . . . . . 26**

    Projector Specifications . . . . . 26

    Timing Chart . . . . . 27

**Dimensions . . . . . 28**

---

# INTRODUCTION

---

---

## Caution

**TO PREVENT SHOCK, DO NOT OPEN THE CABINET. NO USER –SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. PLEASE READ THIS USER'S GUIDE BEFORE YOU OPERATE YOUR PROJECTOR. SAVE THIS USER'S GUIDE FOR FUTURE REFERENCE .**

---

## Safety Instructions

1. Read this user's guide before you operate your projector and save it for future reference.
2. The lamp becomes extremely hot during operation. Allow the projector to cool for approximately 45 minutes prior to removing the lamp assembly for replacement. Do not operate lamps beyond the rated lamp life. Excessive operation of lamps beyond the rated life could cause them to explode on rare occasions.
3. Never replace the lamp assembly or any electronic components unless the projector is unplugged.
4. To reduce the risk of electric shock, do not disassemble this appliance. Take it to a qualified technician when service or repair is required. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
5. Do not place this product on an unstable cart, stand, or table. The product may fall, sustaining serious damage.
6. This product is capable of displaying inverted images for ceiling mount installation. Please use suitable equipment for mounting the unit and ensure it is securely installed.

---

## Caution

- **Always open the lens shutter or remove the lens cap when the projector lamp is on.**
  - **Do not look straight at the projector lens during operation. The intense light beam may damage your eyes.**
  - **In some countries, the line voltage is NOT stable. This projector is designed to operate safely within a bandwidth of 110 to 240 volts, but could fail if power cuts or surges of more than 10 volts occur. In these high-risk areas, it is recommended that a power stabilizer unit be used in conjunction with this projector.**
- 

Save this user's guide: The information contained in this manual will assist you in operating and maintaining your personal projector.

## Warranty

### Limited Warranty

BENQ warrants this product against any defects in material and workmanship, under normal usage and storage.

**Exclusion to Warranty:** The lamps are considered a consumable item and are warranted for 90 days or 500 hours, whichever occurs first. Proof of purchase date will be required with any warranty claim. In the event this product is found to be defective within the warranty period, BENQ's only obligation and your exclusive remedy shall be replacement of any defective parts (labor included). To obtain warranty service, immediately notify the dealer from which you purchased the product of any defects.

**Important:** The above warranty shall be void if the customer fails to operate the product in accordance with BENQ's written instructions. This warranty gives you specific legal rights, and you may have other rights which vary from country to country.

**FCC STATEMENT - CLASS A:** This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class "A" computing device pursuant to Subpart B of Part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his/her own expense will be required to take whatever measures may be required to correct the interference.


**FCC STATEMENT - CLASS B:** This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**EEC STATEMENT:** This machine was tested against the 89/336/EEC (European Economic Community) for EMC (Electro Magnetic Compatibility) and fulfills these requirements.

## Shipping Contents

The Projector is shipped with the cables required for connection to standard PC or laptop computers. Carefully unpack and verify that you have all the items shown below. If any of these items are missing, please contact personnel at the place of purchase.



Projector



User's Guide



Quick Start Guide

User's  
CD Manual


Remote Control




3-2 Converter





Battery




Deluxe Soft Carry Case




Audio Cable

220V 240V 110V  
Power Cord


HDTV Cable




VGA Cable



USB Cable



AV Cable




S-Video Cable

## Optional Accessories


1. Macintosh adapter
2. 210W Lamp module

## Projector Description


### Projector



- |                                             |                          |
|---------------------------------------------|--------------------------|
| ① External control panel<br>(see next page) | ⑪ Audio/ Video connector |
| ② Projection lens                           | ⑫ Audio jack             |
| ③ Front adjuster                            | ⑬ USB mouse connector    |
| ④ IR remote sensor                          | ⑭ S-Video jack           |
| ⑤ Ventilation grill                         | ⑮ RS 232 control port    |
| ⑥ Speaker                                   | ⑯ Rear adjuster feet     |
| ⑦ Projection lens adjuster                  | ⑰ Kensington lock        |
| ⑧ RGB signal input                          | ⑱ AC power cord inlet    |
| ⑨ RGB signal output                         | ⑲ Main power switch      |
| ⑩ YPbPr connector                           | ⑳ Lamp door              |



## External Control Panel



### ① Power

Presses the **Power** key to turn the projector on or off.

### ② Auto

Automatically determines the best picture settings for current received signals.

### ③ Left/ Keystone -

### ④ Exit

### ⑤ Right/ Keystone +

### ⑥ Menu

**Menu** will display the menu system on screen. Press **Menu** again to access the sub-menus. **Left** and **Right** help you navigate among choices and settings in the menus and sub-menus. However, when the on-screen menu is not activated, the **Left** and **Right** buttons will function as **Keystone +/-** hot keys.

Press the **Exit** button to go back to the main menu. Press **Exit** again to leave the menu system.

### ⑦ Source

Selects signal sources from among PC, Video, S-Video and YPBPR.

### ⑧ Lamp Indicator

The Lamp Indicator will light up when the lamp needs service, cooling or replacement. See "Lamp Information" on page 20 for more detailed information.


### ⑨ Temp indicator

The Temp indicator will flash when the system temperature is too high, which may occur if the projector is operated improperly. See "Temp Information" on page 22 for more detailed information.

## Adjuster

The projector is equipped with 2 quick-release adjuster feet. Push the buttons to adjust its tilt angle.

1. Lift the projector up and press the adjuster button to release the adjuster.
2. The adjuster will drop into position and be locked.



## Projector Features

The projector integrates high-performance optical engine projection and a user-friendly design to deliver high reliability and ease of use.


The projector offers the following features:

- Small and light for portability
- Full-function remote control with laser pointer/ remote mouse function
- High quality manual zoom lens
- One-key auto-adjustment to display the best picture quality
- Easy digital keystone correction through hot keys to correct distorted images
- Adjustable color balance control for data/video display
- Ultra-high brightness projection lamp
- Ability to display 16.7 million colors
- On-screen menus in 8 languages: English, French, German, Italian, Spanish, Korean, Simplified Chinese, and Traditional Chinese.
- Switchable Normal/ Video mode for data/ video display
- Powerful AV function to provide high quality AV picture
- HDTV compatibility (YPbPr)

**Note: The brightness of the projected image will vary depending on the ambient lighting conditions and contrast/brightness settings.**

## Remote Control Description

The remote control sensors are located in the front/ back of the projector. The distance between the sensor and the remote control should not exceed 6 meters.




## Installing or Replacing Batteries

**1** Push and slide the battery compartment lid in the direction shown.

**2** Install batteries as indicated by the diagram inside the compartment.

**3** Position the lid over the compartment and snap it back into place.



---

### **Caution**


**Avoid excessive heat and humidity. There may be danger of an explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.**

---

# INSTALLATION

## Screen Size

Place the projector at the required distance from the screen according to the desired picture size (see the table below).



| Screen Size (Max.) |               |                | L. Projection distance (cm) | Screen Size (Min.) |                |
|--------------------|---------------|----------------|-----------------------------|--------------------|----------------|
| Diagonal           | A. Width (cm) | C. Height (cm) |                             | B. Width (cm)      | D. Height (cm) |
| 30.4               | 61.8          | 46.3           | 100                         | 50.7               | 38.0           |
| 60.8               | 123.65        | 92.7           | 200                         | 101.3              | 76.0           |
| 91.2               | 185.3         | 138.9          | 300                         | 151.9              | 113.9          |
| 121.5              | 247.0         | 185.2          | 400                         | 202.5              | 151.9          |
| 151.9              | 308.7         | 231.6          | 500                         | 253.2              | 189.9          |
| 182.3              | 370.5         | 277.9          | 600                         | 303.8              | 227.9          |
| 213.1              | 432.2         | 324.18         | 700                         | 354.4              | 266.2          |
| 243.1              | 494.0         | 370.5          | 800                         | 405.1              | 303.8          |
| 273.5              | 555.7         | 416.7          | 900                         | 455.7              | 341.8          |
| 303.9              | 617.5         | 463.11         | 1000                        | 506.3              | 379.8          |

## Connecting to Various Equipment

### HDTV description

The projector is capable of displaying various High Definition TV display modes. Some of these sources are:

- Digital-VHS (D-VHS) player
- DVD player
- Satellite Dish HDTV receiver
- DTV tuners

Most of these sources will provide an analog component video output, a standard VGA output, or a YPBPR (default) format.

The projector is capable of accepting HDTV data through a YPBPR connector. Use a HDTV cable that came with your projector to display HDTV images.


The following standards are supported in the HDTV function:

- 480i
- 480p
- 720p
- 1080i

Please refer to "Menu System" on page 13 for information on the HDTV OSD selections.

## Connecting to Various Equipment


It only takes a few seconds to connect your projector to your desktop or notebook computer, VCR, or other systems. However, a Mac adapter (an optional accessory) is needed for connection to Macintosh computers.




# OPERATION

## Start Up


1. Plug the power cord into a wall socket.



2. Turn on the main power switch.



3. Press POWER to start the unit. The back-lit POWER key flashes green and stays green when the power is turned on.




(When the power is turned off, there is a 60-second cooling period before the projector can be re-started.)

4. Switch on all connected equipment.


## Digital Keystone Correction

Keystoning refers to the situation where the projected image is noticeably wider at either the top or bottom. To correct this, press KEYSTONE +/- (hot key) on the control panel of the projector or on the remote control, and then adjust the sliding bar labeled Keystone, as needed. Press + to correct keystone at the top of the image. Press - to correct keystone at the bottom of the image.



## Auto Adjustment


In some cases, you may need to optimize the picture quality. To do this, press the AUTO key on the control panel of the projector or on the remote control. Within 3 seconds, the built-in Intelligent Auto Adjustment function will re-adjust settings to provide the best picture quality.




## Source Selection

When several input sources are available, press the **SOURCE** key to make a selection from the control panel of the projector or the remote control.

Projector



Remote control







## Menu System



Press **Menu** for the main menu, and then press ◀ or ▶ to select a sub-menu. Press **Menu** again to select items in the sub-menu.

| Menu Bar       |                                                       |                                                                  |                                                      |                                                                |                                                                                                                                                                                                |
|----------------|-------------------------------------------------------|------------------------------------------------------------------|------------------------------------------------------|----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sub-menu       | Display                                               | Image                                                            | Source                                               | Control                                                        | PIP                                                                                                                                                                                            |
| <b>PC</b>      | Keystone<br>Brightness<br>Contrast<br>Phase<br>H.Size | Ratio<br>H-position<br>V-position<br>Color Temp<br>Information   | Mirror<br>Source<br>Volume<br>Treble<br>Bass<br>Mute | Language<br>OSD<br>Setup<br>Default<br>Video Mode<br>Lamp hour | <b>Main page:</b><br>PIP Source<br>PIP Size<br>PIP Pos.<br>H. Position<br>V.Position<br>More Options<br><br><b>Sub Page:</b><br>Brightness<br>Contrast<br>Color<br>Tint<br>Sharpness<br>System |
| <b>Y/Pb/Pr</b> |                                                       | Ratio<br>H-position<br>V-position<br>Color<br>Tint<br>Color Temp |                                                      |                                                                |                                                                                                                                                                                                |
| <b>Video</b>   |                                                       | Ratio<br>System<br>Sharpness<br>Color Temp<br>Information        |                                                      |                                                                |                                                                                                                                                                                                |





## I. Display Menu

| FUNCTION          | DESCRIPTION                                                                                                                                                                                                                   |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Keystone</b>   | <p>Corrects any keystoneing of the image.</p>                                                                                               |
| <b>Brightness</b> | <p>Adjusts the brightness of the image.</p>                                                                                                 |
| <b>Contrast</b>   | <p>Adjusts the degree of difference between dark and light in the image.</p>                                                               |
| <b>Phase</b>      | <p>Adjusts to avoid the occurrence of flicker.</p>  <p><b>*This function is not available when the input mode is Video or S-Video.</b></p> |
| <b>H.Size</b>     | <p>Adjusts to fit in the desired image size.</p> <p><b>*This function is not available when the input mode is Video or S-Video.</b></p>                                                                                       |
| <b>Color</b>      | <p>Increases or decreases the color range (R, G, B) of the image.</p> <p><b>*This function is not available when the input mode is PC.</b></p>                                                                                |
| <b>Tint</b>       | <p>Adjusts the image to make it appear more red or blue.</p> <p><b>*This function is not available when the input mode is PC.</b></p>                                                                                         |

## 2. Image Menu

| FUNCTION           | DESCRIPTION                                                                                                                                   |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Ratio</b>       | Users have 3 options for the image ratio.<br>1. 1:1    2. 4:3    3. 16:9                                                                      |
| <b>H-position</b>  | Adjusts the horizontal position of the projected image.<br> |
| <b>V-position</b>  | Adjusts the vertical position of the projected image.<br>  |
| <b>Color Temp.</b> | Adjusts the color temperature to fit your preference.                                                                                         |
| <b>Information</b> | Shows the current resolution.                                                                                                                 |
| <b>System</b>      | System information will be shown:<br>1. Auto 2. NTSC 3. PAL 4. SECAM<br><b>*The default setting for System is Auto.</b>                       |
| <b>Sharpness</b>   | Adjusts the image to make it look sharper or softer.<br><b>*This function is not available when the input mode is PC or YPBPR.</b>            |
| <b>Color</b>       | Increases or decreases the color range (R, G, B) of the image.<br><b>*This function is not available when the input mode is PC.</b>           |
| <b>Tint</b>        | Adjusts the image to make it appear more red or blue.<br><b>*This function is not available when the input mode is PC.</b>                    |

### 3. Source Menu



| FUNCTION      | DESCRIPTION                                                                                                           |                                                                                                                                            |
|---------------|-----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Mirror</b> | <b>1. Default</b><br>                | <b>2. Ceiling mounted projection</b><br>                 |
|               | <b>3. Rear screen projection</b><br> | <b>4. Ceiling mounted and rear-screen projection</b><br> |
| <b>Source</b> | Selects the input source from among PC, Video, S-Video, and YPBPr.                                                    |                                                                                                                                            |
| <b>Volume</b> | Adjusts the volume level.<br>      |                                                                                                                                            |
| <b>Treble</b> | Adjusts the treble level.<br>      |                                                                                                                                            |
| <b>Bass</b>   | Adjusts the bass level.<br>        |                                                                                                                                            |
| <b>Mute</b>   | <b>Off</b>                                                                                                            | <b>On</b>                                                                                                                                  |
|               |                                    |                                                         |

## 4. Control Menu

| FUNCTION          | DESCRIPTION                                                                                                                                                                                                      |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Language</b>   | Language sets the language for the OSD control menus. Use the ◀ / ▶ key to select the desired language from among English, French, German, Italian, Spanish, Korean, Simplified Chinese and Traditional Chinese. |
| <b>OSD</b>        | <b>OSD Pos.</b><br>Selects a desired OSD position.                                                                                                                                                               |
|                   | <b>OSD Time</b><br>Sets the length of time the OSD will remain active after the last time you pressed the button. The range is from 5 to 60 seconds in 5-second increments.                                      |
| <b>Setup</b>      | <b>Source Scan</b><br>When selected, activates the Source scan function.                                                                                                                                         |
|                   | <b>Keystone hold</b><br>When selected, preserves the last keystone correction value even when the projector is restarted.                                                                                        |
|                   | <b>Mirror hold</b><br>When selected, preserves the last mirror correction value even when the projector is restarted.                                                                                            |
|                   | <b>Blank time</b><br>Determines the length of time before the projector is shut off when Blank is activated.                                                                                                     |
|                   | <b>Auto Off</b><br>Sets the length of time before the system is shut off when no input is detected.                                                                                                              |
|                   | <b>User logo</b><br>Enables the user to define his/her own logo screen that will display during start-up. Three modes are available: Default (BENQ logo), black screen and blue screen.                          |
| <b>Default</b>    | Returns all settings to their factory preset values.                                                                                                                                                             |
| <b>Video Mode</b> | Selects video mode.                                                                                                                                                                                              |
| <b>Lamp hour</b>  | Shows lamp usage time.                                                                                                                                                                                           |


## 5. PIP Menu

These functions are available only when the input mode is PC and the PIP source is Video or S-Video.


| FUNCTION            | DESCRIPTION                                                                                                                                                                                |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PIP Source</b>   | Selects the source for the PIP.                                                                                                                                                            |
| <b>PIP Size</b>     | <p>Enables use of the ◀ / ▶ key to scroll through the four alternatives: Off, Small, Medium, Large.</p>  |
| <b>PIP Position</b> | <p>Selects a desired position for the PIP.</p>                                                          |
| <b>H. Position</b>  | Adjusts the horizontal position of the PIP image.                                                                                                                                          |
| <b>V. Position</b>  | Adjusts the vertical position of the PIP image.                                                                                                                                            |
| <b>More Options</b> | Enables use of the ◀ / ▶ key to select more PIP functions including Brightness, Contrast, Color, Tint, Sharpness and System.                                                               |
| <b>Brightness</b>   | Adjusts the brightness of the PIP image.                                                                                                                                                   |
| <b>Contrast</b>     | Adjusts the degree of difference between dark and light for the PIP image.                                                                                                                 |
| <b>Color</b>        | Increases or decreases the color range (R, G, B) of the image.                                                                                                                             |
| <b>Tint</b>         | Adjusts the image to make it appear more red or blue.                                                                                                                                      |
| <b>Sharpness</b>    | Adjusts the image to make it appear sharper or softer                                                                                                                                      |
| <b>System</b>       | Selects PIP image systems: Auto, NTSC, PAL, SECAM                                                                                                                                          |

## Shutdown


1. Press **POWER** and a warning message will appear. To turn off the projector, press **POWER** again.



2. The fan will continue to run for approximately two minutes.
3. Turn off the main power switch.



4. Disconnect the power cord from the wall socket.



### Caution

Please do not unplug the power cord before **POWER** is shut down or during the two-minute cooling process.

If the projector is not properly shut down, to protect the lamp, the system will detect this and cool the lamp for two minutes automatically before turning on again.

# MAINTENANCE

## Lamp Information

### Use and Replacement of the Lamp

When the Lamp Indicator lights up red or a message appears suggesting the time of lamp replacement, please install a new lamp or consult your dealer. An old lamp could cause a malfunction in the projector and in rare instances may even explode.

### Lamp LED Indicators

|                                          |                                                                                                                                                                                                                                                                                                    |
|------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Lamp Life Indicators</b>              | When the LED lights up red, it is warning you that lamp uage has exceeded <b>1500</b> hours. Replace the projection lamp with a new one immediately.                                                                                                                                               |
| <b>The Lamp is not properly attached</b> | LED lights up red.                                                                                                                                                                                                                                                                                 |
| <b>The temperature is too high</b>       | When the projector's internal temperature is too high for the projector to operate safely, the LED blinks orange and the lamp turns off automatically. The LED keeps blinking while the unit is off.<br>If the LED light is off, the operation and temperature of the projector's lamp are normal. |



### Caution

**The LAMP indicator will light up if the lamp becomes too hot. Turn off the power and let the projector cool for 45 minutes. If the LAMP indicator is still red when turning the power on, please contact your dealer.**

---


## Lamp Replacement

### Caution


To reduce the risk of electrical shock, always turn off the projector and disconnect the power cord before changing the lamp.

1. Press the **POWER** button to switch off the projector. Disconnect the power cord from the outlet and the projector.
2. Loosen the screw and remove the lamp cover. If the lamp is hot, avoid burns by waiting 45 minutes until the lamp has cooled.
3. Loosen the 3 screws. (It is strongly recommended that you use a magnetic-head screwdriver.) Pull the handle to remove the lamp housing. If the screws are not loosened completely, they could injure your fingers. Do not insert your hand into the box after the lamp is removed. If you touch the optical components inside, this could cause color unevenness in projected images.
4. Replace the lamp with a new one. Insert it into the projector, and tighten the screws firmly. Loose screws may cause a bad connection, which may result in malfunction.
5. Re-install the lamp cover and tighten the screw. **Do not turn on the power with the lamp cover removed.** Whenever the lamp is replaced, reset the total lamp operation time. **Do not reset if the lamp is not replaced as this could cause damage.**


#### Step 1




#### Step 2



#### Step 3



#### Step 4



## Caution

To reduce the risk of severe burns, allow the projector to cool for at least 45 minutes before replacing the lamp.



To reduce the risk of injuries to fingers and damage to internal components, use caution when removing lamp glass that has shattered into sharp pieces.

To reduce the risk of injuries to fingers and/or compromising image quality by touching the lens, do not touch the empty lamp compartment when the lamp is removed.

This lamp contains mercury. Consult your local hazardous waste regulations to dispose of this lamp in a proper manner.

## Resetting Lamp Hours

If you replace the lamp after 1500 hours of operation, please follow the instructions below within 10 minutes of powering on.

| OSD                                                                                 | FUNCTION                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Press the Exit button on the projector for 3 seconds to display the total used lamp time.                                                                                                                                   |
|  | <ul style="list-style-type: none"> <li>Press the MENU button on the projector during the lamp hour message. An adjustment message will appear.</li> <li>Press ◀ or ▶ to reset lamp hours or press EXIT to leave.</li> </ul> |

## Temp Information

When the LED lights up, it is warning you of the following possible problems:

1. The internal temperature is too high.
2. The fans are not working.

Turn off the projector and contact qualified service personnel for further help.

## Service Information

### Accessories (included in the Standard Package)

| <b>Description</b>  | <b>Part Number</b> |
|---------------------|--------------------|
| Power cord (EU)     | 27.82718.281       |
| Power cord (US)     | 27.01818.000       |
| Power cord (UK)     | 27.02718.201       |
| Signal cable        | 50.J0508.502       |
| Video cable         | 50.J2918.001       |
| S-Video cable       | 50.72920.011       |
| PC - PC audio cable | 50.74405.501       |
| Soft carrying case  | 98.J3402.B11       |
| HDTV cable          | 50.J7111.501       |
| USB mouse cable     | 50.73213.501       |
| Remote control      | 98.J3401.B11       |
| 3-2 converter       | 22.91007.001       |

### Optional Accessories (not included in the Standard Package)

| <b>Description of parts</b> | <b>Part number</b> |
|-----------------------------|--------------------|
| Mac adapter (switchable)    | 20.20118.A15       |
| 210W lamp module            | 60.J3004.001       |

### Ordering Parts or Getting Information

For product information, product assistance, service information, or to order accessories, please see the BENQ corporation website at <http://www.BenQ.com>.

# TROUBLESHOOTING

## Common Problems & Solutions

| PROBLEMS                             | TRY THESE SOLUTIONS                                                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NO POWER</b>                      | <ul style="list-style-type: none"> <li>• Make sure the power cord is inserted snugly into the AC adapter socket.</li> <li>• Make sure the power cord is inserted snugly into the power outlet.</li> <li>• Toggle the power switch to the position "I".</li> <li>• Wait two minutes after the projector is turned off before turning the projector back on.</li> </ul>     |
| <b>NO PICTURE</b>                    | <ul style="list-style-type: none"> <li>• Check for the proper input source.</li> <li>• Ensure all cables are connected properly.</li> <li>• Adjust the brightness and contrast.</li> <li>• Remove the lens cap.</li> </ul>                                                                                                                                                |
| <b>TRAPEZOID IMAGE ON THE SCREEN</b> | <ul style="list-style-type: none"> <li>• Reposition the unit to improve its angle on the screen.</li> <li>• Use the <b>Keystone</b> correction key on the control panel of the projector or the remote control unit.</li> </ul>                                                                                                                                           |
| <b>POOR COLOR</b>                    | <ul style="list-style-type: none"> <li>• Select the correct video system.</li> <li>• Adjust brightness, contrast, or saturation.</li> </ul>                                                                                                                                                                                                                               |
| <b>BLURRED IMAGE</b>                 | <ul style="list-style-type: none"> <li>• Press <b>Auto</b> on the control panel of the projector or the remote control unit to get better picture quality.</li> <li>• Adjust the focus.</li> <li>• Reposition the unit to improve its projection angle.</li> <li>• Ensure the distance between the unit and screen is within the adjustment range of the lens.</li> </ul> |
| <b>REMOTE CONTROL DOES NOT WORK</b>  | <ul style="list-style-type: none"> <li>• Replace the batteries with new ones.</li> <li>• Make sure there is no obstacle between the remote control and the projector.</li> <li>• Stand within 4 meters (13 feet) of the projector.</li> <li>• Make sure nothing is blocking the front and rear receivers.</li> </ul>                                                      |

## Status Messages

| On-Screen Messages                                                  | Description                                                                                                                                                                                                     |
|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SEARCHING</b>                                                    | Projector is searching for input.                                                                                                                                                                               |
| <b>ACQUIRING SIGNAL</b>                                             | Projector has identified the input signal and is running the auto image adjustment function.                                                                                                                    |
| <b>OUT OF RANGE</b>                                                 | Input signal frequency exceeds the projector's range.                                                                                                                                                           |
| <b>LAMP WARNING -<br/>CHANGE LAMP AND<br/>RESET LAMP TIMER!</b>     | The lamp has been in operation for 1400 hours. Install a new lamp for optimal performance.                                                                                                                      |
| <b>OUT OF LAMP USAGE<br/>TIME. CHANGE THE<br/>LAMP!</b>             | The lamp has been in operation for 1480 hours, and the power will turn off after 20 hours.                                                                                                                      |
| <b>OUT OF LAMP USAGE<br/>TIME. YOU HAVE TO<br/>CHANGE THE LAMP!</b> | The lamp has been in operation for over 1500 hours. The warning message will display for 30 seconds every 5 minutes after you turn on the projector and the power will turn off automatically after 10 minutes. |

# SPECIFICATIONS

## Projector Specifications

### Technical Specifications

**Note:** All specifications are subject to change without notice.

#### General

|              |                             |
|--------------|-----------------------------|
| Product name | Personal Projector          |
| Model name   | DX660/650      1024X768 XGA |
|              | DS660/650      800X600 SVGA |

#### Optical

|                |               |
|----------------|---------------|
| Display system | I-CHIP DMD    |
| Lens F/Number  | F/2.6         |
| Lamp           | 210W NSH lamp |

#### Electrical

|                   |                                          |
|-------------------|------------------------------------------|
| Power supply      | AC100 ~ 240V, 3.5A, 50/60 Hz (Automatic) |
| Power consumption | 330 W (Max)                              |

#### Mechanical

|                             |                                     |
|-----------------------------|-------------------------------------|
| Dimensions                  | 308 mm (W) x 95 mm (H) x 238 mm (D) |
| Operating temperature range | 10°C ~ 40°C                         |
| Weight                      | 6.8 lbs (3.1 Kg)                    |

#### Input terminal

|                    |                        |
|--------------------|------------------------|
| Computer input     |                        |
| RGB input          | D-sub 15-pin (female)  |
| Video signal input |                        |
| S-VIDEO            | Mini DIN 4-pin port x1 |
| VIDEO              | RCA jack x1            |
| HDTV signal input  | YPbPr RCA jack x3      |
| Audio signal input |                        |
| Audio 1            | Mini jack stereo port  |
| Audio 2            | RCA jack L, R x2       |

#### Output

|                     |               |
|---------------------|---------------|
| USB mouse connector | A/B series x1 |
| Speaker             | 3 watt x 1    |


#### Control

|         |          |
|---------|----------|
| RS-232C | 9-pin x1 |
|---------|----------|

## Timing Chart

| Resolution | H Sync (kHz) | V Sync (Hz) | Remark    |
|------------|--------------|-------------|-----------|
| 640x350    | 31.5         | 70.1        |           |
| 640x400    | 37.9         | 85.1        | VESA      |
| 720x400    | 31.5         | 70.0        |           |
| 720x400    | 37.9         | 85.1        | VESA      |
| 640x480    | 31.5         | 60.0        | VESA      |
| 640x480    | 37.9         | 72.8        | VESA      |
| 640x480    | 35           | 66.7        | Macintosh |
| 640x480    | 43.3         | 85.0        | VESA      |
| 800x600    | 35.2         | 56.3        | VESA      |
| 800x600    | 37.9         | 60.3        | VESA      |
| 800x600    | 46.9         | 75.0        | VESA      |
| 800x600    | 48.1         | 72.2        | VESA      |
| 800x600    | 53.7         | 85.1        | VESA      |
| 832x624    | 49.7         | 74.5        | Macintosh |
| 1024x768   | 48.4         | 60.0        | VESA      |
| 1024x768   | 56.5         | 70.1        | VESA      |
| 1024x768   | 60.0         | 75.0        | VESA      |
| 1024x768   | 68.7         | 85.0        | VESA      |
| 1280x1024  | 64.0         | 60.0        | VESA      |

## DIMENSIONS



Unit: mm