

SONY[®]

2-597-544-12(1)

GRAND WEGA[™]

LCD Projection TV
HD-TV
Operating Instructions

KDF-E42A10
KDF-E50A10



Owner's Record

The model and serial numbers are located at the rear of the TV. Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. _____

Serial No. _____

Contacting Sony

If, after reading the following instructions, you have additional questions related to the use of your Sony® TV, please call one of the following numbers.

Customers in the continental United States contact the Direct Response Center at:

1-800-222-SONY (7669)

or visit <http://www.sonystyle.com/tv/>

Customers in Canada contact the Customer Relations Center at:

1-877-899-SONY (7669)

or visit <http://www.sonystyle.ca/tv/>

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

CAUTION

To prevent electric shock, do not use this polarized AC plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

CAUTION

When using TV games, computers, and similar products with your projection TV, keep the brightness and contrast functions at low settings. If a fixed (non-moving) pattern is left on the screen for long periods of time at a high brightness or contrast setting, the image can be permanently imprinted onto the screen. Continuously watching the same program can cause the imprint of station logos onto the TV screen. These types of imprints are not covered by your warranty because they are the result of misuse.

Note on Caption Vision

This TV provides display of TV closed captioning in accordance with §15.119 of the FCC rules.

For Customers in the United States

If you have any questions about this product, you may call; Sony Customer Information Services Center 1-800-222-7669 or <http://www.sony.com/>

Declaration of Conformity

Trade Name: SONY
Model: KDF-E42A10/KDF-E50A10
Responsible Party: Sony Electronics Inc.
Address: 16450 W. Bernardo Dr.,
San Diego, CA 92127 U.S.A.
Telephone Number: 858-942-2230

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTIFICATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

For Customers in Canada

This Class B digital apparatus complies with Canadian ICES-003.

Safety

- Operate the TV only on 120 V AC.
- Use the AC power cord specified by Sony and suitable for the voltage where you use it.
- The plug is designed, for safety purposes, to fit into the wall outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- If any liquid or solid object should fall inside the cabinet, unplug the TV immediately and have it checked by qualified service personnel before operating it further.
- If you will not be using the TV for several days, disconnect the power by pulling the plug itself. Never pull on the cord.
- For details concerning safety precautions, see “Important Safety Instructions” on page 5.

Installing

- The TV should be installed near an easily accessible power outlet.
- To prevent internal heat buildup, do not block the ventilation openings.
- Do not install the TV in a hot or humid place, or in a place subject to excessive dust or mechanical vibration.
- Avoid operating the TV at temperatures below 41°F (5°C).
- If the TV is transported directly from a cold to a warm location, or if the room temperature changes suddenly, the picture may be blurred or show poor color due to moisture condensation. In this case, please wait a few hours to let the moisture evaporate before turning on the TV.

(Continued)

- To obtain the best picture, do not expose the screen to direct illumination or direct sunlight. It is recommended to use spot lighting directed down from the ceiling or to cover the windows that face the screen with opaque drapery. It is desirable to install the TV in a room where the floor and walls are not of a reflective material.
- See pages 13 and 14 for more information on the installation.

HDMI This TV incorporates High-Definition Multimedia Interface (HDMI™) technology. HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

CAUTION

Use the following Sony appliance(s) only with the following TV STAND.

Use with other TV STAND may cause instability and possibly result in injury.

SONY APPLIANCE MODEL NO.

KDF-E42A10

KDF-E50A10

SONY TV STAND MODEL NO.

SU-RG11S (KDF-E42A10)

SU-RG11M (KDF-E50A10)

To Customers

Sufficient expertise is required for installing the specified product. Be sure to subcontract the installation to Sony dealers or licensed contractors and pay adequate attention to safety during the installation.

For Customers in the United States

This product contains mercury. Disposal of this product may be regulated if sold in the United States. For disposal or recycling information, please contact your local authorities or the Electronics Industries Alliance (<http://www.eiae.org>).

Note

This digital television is capable of receiving analog basic, digital basic and digital premium cable television programming by direct connection to a cable system providing such programming. A security card provided by your cable operator is required to view encrypted digital programming. Certain advanced and interactive digital cable services such as video-on-demand, a cable operator's enhanced program guide and data-enhanced television services may require the use of a set-top box. For more information call your local cable operator.

This television also includes a QAM demodulator which should allow you to receive unscrambled digital cable television programming via subscription service to a cable service provider. Availability of digital cable television programming in your area depends on the type of programming and signal provided by your cable service provider.

Trademark Information

CableCARD™ is a trademark of Cable Television Laboratories, Inc.

TruSurround XT, SRS and the (●)* symbol are trademarks of SRS Labs, Inc. TruSurround XT technology is incorporated under license from SRS Labs, Inc.

Licensed by BBE Sound, Inc. under USP4638258, 4482866. "BBE" and BBE symbol are trademarks of BBE Sound, Inc.

Macintosh is a trademark licensed to Apple Computer, Inc., registered in the U.S.A and other countries.

WEGA, Grand WEGA, WEGA GATE, Steady Sound, Digital Reality Creation and CineMotion are registered trademarks of Sony Corporation.

"PlayStation" is a trademark of Sony Computer Entertainment, Inc.



This TV is manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

Important Safety Instructions


- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.



- 6) Clean only with dry cloth.



- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.



- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.



- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.



- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.



- 11) Only use attachments/accessories specified by the manufacturer.



- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.



- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



- Be sure to observe the TV's "For Safety" section on page 6.

Antennas

Outdoor Antenna Grounding

If an outdoor antenna is installed, follow the precautions below. An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits.

WHEN INSTALLING AN OUTDOOR ANTENNA SYSTEM, EXTREME CARE SHOULD BE TAKEN TO KEEP FROM CONTACTING SUCH POWER LINES OR CIRCUITS AS CONTACT WITH THEM IS ALMOST INVARIABLY FATAL.


Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

Section 810 of the National Electrical Code (NEC) in USA and Section 54 of the Canadian Electrical Code in Canada provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

(Continued)

Antenna Grounding According to the NEC

Refer to section 54-300 of Canadian Electrical Code for Antenna Grounding.



Cleaning

- Clean the rear cover area of the TV regularly. Dust in the rear cover area may cause a problem with the cooling system of the TV set.
- Clean the cabinet of the TV with a dry soft cloth. To remove dust from the screen, wipe it gently with a soft cloth. Stubborn stains may be removed with a cloth slightly dampened with solution of mild soap and warm water. Never use strong solvents such as thinner or benzine for cleaning. If the picture becomes dark after using the TV for a long period of time, it may be necessary to clean the inside of the TV. Consult qualified service personnel.
- Unplug the AC power cord when cleaning this unit. Cleaning this unit with a plugged AC power cord may result in electric shock.



On Contamination on the Screen Surface

The screen surface has a special coating to reduce reflections. To prevent screen damage, clean the screen as follows:

- Clean the screen with a soft cloth.
- To remove hard contamination, use a cloth moistened with a solution of mild detergent and water. Do not spray cleaning solution directly onto the TV. It should only be sprayed to moisten the cleaning cloth.
- Do not use any type of abrasive pad, alkaline cleaner, acid cleaner, scouring powder, chemical cloth, or solvent such as alcohol, benzene or thinner, as these may scratch the screen's coating.

Service

Damage Requiring Service

Do not attempt to service the set by yourself since opening the cabinet may expose you to dangerous voltage or other hazards.

Unplug the set from the wall outlet and refer servicing to qualified service personnel.



Replacement Parts

When replacement parts are required, be sure the service technician certifies in writing that he has used replacement parts specified by the manufacturer that have the same characteristics as the original parts.

Unauthorized substitutions may result in fire, electric shock or other hazards.

See "Replacing the Lamp" on page 86.

For Safety

Be Careful When Moving the TV

When you place the TV in position, be careful not to drop it on your foot or fingers.


Watch your footing while installing the TV.



Carry the TV in the Specified Manner

If you carry the TV in a manner other than the specified manner and without the specified number of persons, it may drop and a serious injury may be caused. Be sure to follow the instructions mentioned below.

- Carry the TV with the specified number of persons (see page 13).
- Hold the TV tightly when carrying it.
- Before carrying the TV, disconnect any accessories or cables.



About the TV

Although the TV is made with high-precision technology, black dots may appear or bright points of light (red, blue, or green) may appear constantly on the screen. This is a structural property of the panel and is not a defect.

Installation

- If direct sunlight or other strong illumination shines on the screen, part of the screen may appear white due to reflections from behind the screen. This is a structural property of the TV. Do not expose the screen to direct illumination or direct sunlight.
- The picture quality may be affected by your viewing position. For the best picture quality, install your TV according to "Recommended Viewing Area" on page 14.
- When installing your TV against a wall, keep it at least 4 inches (10 cm) away from the wall.

Projection Lamp

- Your TV uses a projection lamp as its light source. It is time to replace the lamp with a new one (not supplied) when:
 - the lamp replacement indicator on the front panel blinks in red,
 - screen images become dark,
 - no image appears on the display after prolonged use.
- In rare instances, the bulb may pop inside the lamp unit, but the lamp unit is designed to contain all of broken glass pieces inside the lamp unit. (See "Replacing the Lamp" on page 86.)
- When the lamp eventually burns out, you may hear a noticeable pop sound. This is normal and is inherent in this type of lamp.

Disposal of Used Batteries

To preserve our environment, dispose of used batteries according to your local laws or regulations.

Cooling Fan

This TV uses a cooling fan. You may hear the noise of fan running, depending on the placement of your TV. The noise may be more noticeable during the night or when the background noise level is low.

Contents

Introducing the TV

| | |
|---|-----------|
| Welcome | 9 |
| Package Contents..... | 9 |
| Features..... | 9 |
| Enjoying Your TV | 11 |
| Notes on the TV..... | 11 |
| Screen..... | 11 |
| Indicators..... | 12 |
| Projection Lamp..... | 12 |
| Installing the TV | 13 |
| Carrying Your TV..... | 13 |
| Take Precaution during Installation..... | 13 |
| Preventing the TV from Toppling Over..... | 14 |
| When Installing Your TV against a Wall..... | 14 |
| Recommended Viewing Area..... | 14 |
| TV Controls and Connectors | 15 |
| Front Panel..... | 15 |
| Side Panel..... | 16 |
| Rear Panel..... | 17 |

Connecting the TV

| | |
|--|-----------|
| Overview | 19 |
| Making Video and Audio Connections..... | 19 |
| About Using S VIDEO..... | 20 |
| About Using HDMI to DVI Adapter..... | 20 |
| Basic Connections | 21 |
| Cable System or VHF/UHF..... | 22 |
| Cable Box and Antenna..... | 23 |
| Cable Box..... | 24 |
| Satellite Receiver..... | 25 |
| Digital Cable Box or Digital Satellite Receiver..... | 26 |
| Equipment with HDMI Connection..... | 27 |
| Equipment with DVI Connection..... | 28 |
| Equipment with Digital Audio (Optical)..... | 29 |
| Using CableCARD Device | 30 |
| About Using CableCARD Device..... | 30 |
| Activating CableCARD Service..... | 30 |
| Removing the CableCARD Device..... | 31 |
| Setting Up the Channel List | 32 |
| Using Initial Setup..... | 32 |

| | |
|---|-----------|
| Connecting Optional Equipment | 33 |
| VCR and Cable..... | 34 |
| VCR and Cable Box..... | 35 |
| Two VCRs for Tape Editing..... | 37 |
| DVD Player with Component Video Connectors..... | 38 |
| DVD Player with S VIDEO and Audio Connectors..... | 39 |
| Personal Computer..... | 40 |
| Camcorder or “PlayStation”..... | 41 |
| Audio Receiver..... | 42 |

Watching the TV

| | |
|---|-----------|
| Overview | 43 |
| Inserting Batteries into the Remote Control | 43 |
| Button Descriptions | 44 |
| Programming the Remote Control | 47 |
| Using Other Equipment with Your Remote Control | 49 |
| Special Buttons on the Remote Control | 51 |
| Using the GUIDE Button..... | 51 |
| Using the WIDE Button..... | 53 |
| Using the JUMP Button..... | 54 |
| Using the FREEZE Button..... | 54 |

Introducing WEGA GATE

| | |
|---|-----------|
| Overview of WEGA GATE | 55 |
| Navigating and Selecting Items | 57 |
| Using Favorites in WEGA GATE | 57 |
| Using Cable in WEGA GATE | 58 |
| Using Antenna in WEGA GATE | 58 |
| Using External Inputs in WEGA GATE | 59 |
| Using Settings in WEGA GATE | 59 |

Using the Settings

| | |
|---|-----------|
| Overview | 61 |
| Accessing the Video Settings | 63 |
| Selecting Video Options..... | 63 |
| Selecting PC Video Options..... | 65 |
| Accessing the Audio Settings | 66 |
| Selecting Audio Options..... | 66 |
| Selecting PC Audio Options..... | 68 |

| | |
|--|-----------|
| Accessing the Screen Settings | 69 |
| Selecting Screen Options | 69 |
| Selecting PC Screen Options | 71 |
| Accessing the Channel Settings | 72 |
| Selecting Channel Options | 72 |
| Accessing the Parental Lock Settings..... | 74 |
| Selecting Parental Lock Options | 74 |
| Viewing Blocked Programs | 75 |
| Selecting Custom Rating Options | 76 |
| Accessing the Setup Settings | 78 |
| Selecting Setup Options | 78 |
| Programming Caption Vision | 80 |
| Selecting PC Setup Options | 81 |
| Accessing the Applications Settings..... | 83 |
| Selecting Applications Options | 83 |

Other Information

| | |
|--------------------------------|-----------|
| Overview..... | 85 |
| Contacting Sony | 85 |
| Replacing the Lamp..... | 86 |
| How to Replace the Lamp..... | 86 |
| Troubleshooting | 90 |
| Remote Control..... | 90 |
| CableCARD Device | 90 |
| Video..... | 91 |
| Audio..... | 92 |
| Channels..... | 92 |
| General | 93 |
| Specifications | 94 |

Index

| | |
|--------------------|-----------|
| Index | 96 |
|--------------------|-----------|

Introducing the TV

Welcome

Thank you for purchasing this Sony's *HD* LCD projection TV. This manual is for models KDF-E42A10 and KDF-E50A10.

Package Contents

Along with your new TV, the packing box contains a remote control and two AA (R6) batteries. See page 95 for the complete list of packaging contents.

Features

Some of the features that you will enjoy with your new TV include:

- ❑ **WEGA GATE™:** WEGA GATE is a new feature that allows you to easily navigate to the most convenient TV functions: favorite channels, cable channels, antenna channels, external input list or settings.
- ❑ **WEGA Engine:** Delivers superb picture quality from any video source by minimizing the signal deterioration caused by digital-to-analog conversion and stabilizing the signal processing. This engine features unique Sony technology, including:
 - **DRC® (Digital Reality Creation)-MF V1:** Unlike conventional line doublers, the DRC Multifunction feature replaces the signal's NTSC waveform with the near-HD equivalent by digital mapping processing. The DRC Palette option lets you customize the level of detail (Reality) and smoothness (Clarity) to create up to three custom palettes.
- ❑ **Integrated HDTV:** You can watch digital television programs and enjoy the improved audio/video quality offered by these programs.
- ❑ **Wide Screen Mode:** Allows you to watch 4:3 normal broadcasts in wide screen mode (16:9 aspect ratio).
- ❑ **Advanced Iris:** This advanced iris shutter works automatically open and close according to the incoming signal level to create brighter whites and better contrast in dark scenes.
- ❑ **CineMotion®:** Using the reverse 3-2 pull down technology, the CineMotion feature provides smoother picture movement when playing back movies or other video sources on film.
- ❑ **Parental Control:** V-Chip technology allows parents to block unsuitable programming from younger viewers.
- ❑ **CableCARD™ slot:** Provides cable subscribers with access to digitally encrypted cable channels — without the need for a set-top box — that will enable you to receive not only standard definition but also high definition television. The CableCARD device, which is provided by your cable TV company, is inserted into the TV's rear panel

(Continued)

CableCARD slot. After the service is activated with your cable TV company, the card replaces the need for a separate set-top box. (Check with your cable TV company about CableCARD service details, limitations, pricing, and availability. For more information about the CableCARD device in this manual, see page 30.)

- ❑ **Component Video Inputs:** Offers the best video quality for DVD (480p, 480i) and digital set-top box (1080i, 720p, 480p, 480i) connections.
- ❑ **S VIDEO Inputs:** Provides a high-quality image from connected equipment.
- ❑ **Favorite Channels:** With the WEGA GATE function, it allows you to navigate a list of up to 16 favorite channels without leaving the current channel.
- ❑ **Steady Sound[®]:** Equalizes volume levels so there is consistent output between programs and commercials.
- ❑ **HDMI (High-Definition Multimedia Interface):** Provides an uncompressed, all-digital audio/video interface between this TV and any HDMI-equipped audio/video component, such as a set-top box, DVD player, and A/V receiver. HDMI supports enhanced, or high-definition video, plus two-channel digital audio.

Enjoying Your TV

To enjoy your TV for years to come and maintain its original picture quality, you should perform periodic maintenance.

Notes on the TV

To enjoy clear picture

- Prevent sunlight or other light sources from shining directly on to the screen.
- The screen surface is easily scratched. Do not rub, touch, or tap it with sharp or abrasive objects (see “On Contamination on the Screen Surface” on page 6).

When not using the TV for a long period of time

- Unplug the AC power cord from the outlet if you anticipate not using the TV for more than a week.

When turning off the power

- The cooling fan will continue to operate for about two minutes. Allow several minutes before unplugging from the outlet or switching the breaker off.

On moisture condensation

- If your TV is moved directly from a cold to a warm location or is placed in a humid room, or if the room temperature changes suddenly, the picture may blur or show poor color. This is caused by moisture condensation on the lenses inside. Wait a few hours to let the moisture evaporate before turning on the TV. When the condensation has evaporated, the picture will return to normal.


Screen

To minimize reflection, the screen surface has a special coating. Inappropriate cleaning methods could damage the screen surface. Special care is required.

Cleaning the Screen Surface

Dust and dirt on the screen can affect the picture quality. To dust off the screen use a soft cloth. Be sure to follow the cleaning instruction on page 6 for stubborn stains and dirt.

Indicators



The indicators show the current status of your TV. If there is a change in the condition or a problem with the TV, the indicators will flash or light up in the manner described below to let you know that it requires your attention.


| <i>Indicator</i> | <i>Flashing because...</i> |
|----------------------------|--|
| POWER/ STANDBY flashing | green : The lamp for the light source is preparing to turn on. When it is ready, it turns on. red : The lamp door or the lamp is not securely attached. The red indicator will continue to flash in intervals of three blinks at a time until the lamp door or the lamp is placed correctly. When the lamp door or the lamp is securely attached, the TV will turn on with green indicator. |
| LAMP indicator flashes | The projection lamp has burned out. Replace it with new one (see page 86). |
| TIMER indicator is lit | When one of the timers is set, the indicator will remain lit (will not flash) even when the TV is turned off. |

Projection Lamp

How to replace the lamp,
see page 86.

Your TV uses a projection lamp as its light source. As with any lamp, it has lifespan and needs to be replaced when the Lamp indicator flashes or the screen becomes darker. Note the following:


- After turning on your TV, it may take a while (1 minute or less) before the picture appears.
- When the projection lamp wears out, the screen goes dark. Replace the lamp with a new Sony XL-2400 replacement lamp (not supplied).

 **The light emitted from the lamp is quite bright when your TV is in use. To avoid eye discomfort or injury, do not look into the light housing when the power is on.**

Installing the TV


Carrying Your TV

Carrying the TV requires at least two people. Do not hold by the pedestal or the front panel of the TV. Doing so may cause these parts to break off.




When moving the TV, place one hand in the hole on the lower portion of the TV while grasping the top with the other hand, as shown in the illustration below.

KDF-E42A10



KDF-E50A10



If you have connected cables and cords, be sure to unplug them before moving the TV.

Take Precaution during Installation


To ensure the safety of children and the TV, keep children away from the TV during installation. Climbing on or pushing the TV or its stand may cause it to fall and damage the TV.

Preventing the TV from Toppling Over

As a protective measure, secure the TV as follows.

Using the TV stand with support belts

- ❑ Sony strongly recommends using the TV stand SU-RG11S (for KDF-E42A10)/SU-RG11M (for KDF-E50A10) with a support belt designed for your TV.



👉 **When using the SU-RG11S (for KDF-E42A10)/SU-RG11M (for KDF-E50A10) stand for your TV, you must use the support belt.**

When Installing Your TV against a Wall

Keep your TV at least 4 inches (10 cm) away from the wall to provide proper ventilation.

Recommended Viewing Area

Your viewing position may affect the picture quality.

For the best picture quality, install your TV within the areas shown below.

Model



KDF-E42A10

KDF-E50A10

Viewing distance


min. 5.9 ft. (approx. 1.8 m)

min. 6.6 ft. (approx. 2.0 m)



TV Controls and Connectors

Front Panel




Introducing the TV

| Item | Description |
|------|--|
| 1 | WEGA GATE Press to display WEGA GATE and activate the \pm , \leftarrow , \rightarrow , \downarrow , and \uparrow buttons. Press again to exit WEGA GATE and activate the TV/VIDEO, - VOLUME + and - CHANNEL+ buttons. |
| 2 | \pm TV/VIDEO Press to confirm the selection or setting. Press repeatedly to cycle through the video equipment connected to the TV's video inputs. |
| 3 | \leftarrow \rightarrow - VOLUME + Press to adjust the volume. |
| 4 | \downarrow \uparrow - CHANNEL + Press to scan through channels. To scan quickly through channels, press and hold either - or +. |
| 5 | TIMER LED When lit, indicates one of the timers or Sleep is set. When it is set, this LED will remain lit even if the TV is turned off. For details, see page 83. |
| 6 | LAMP LED Lights up in red when the lamp for the light source has burned out. For details, see "Replacing the Lamp" on page 86. |
| 7 | POWER/STANDBY LED Lights up in green when the TV is turned on. If the LED blinks in red continuously, this may indicate the display unit needs servicing (see "Contacting Sony" on page 2). When the red LED blinks only three times, the lamp door of the lamp unit or the lamp itself is not securely attached (see page 88). |
| 8 | (IR) Infrared Receiver Receives IR signals from the remote control. Do not put anything near the sensor, as its function may be affected. |
| 9 | POWER Press to turn on and off the TV. |
| 10 | Speaker Outputs audio signal. |


The CHANNEL + button has a tactile dot. Use the tactile dot as a reference when operating the TV.

Side Panel



| Jack | Description |
|---|--|
| 1 HD/DVD IN 2 (1080i/720p/480p/480i) | Connect to your DVD player's or digital set-top box's component video (YPbPr) and audio (L/R) jacks. Component video provides better picture quality than the S VIDEO (5) of rear panel) or the composite video (6) of rear panel) connections (see page 18). |
| 2 VIDEO IN 2 VIDEO/ AUDIO L (MONO)/ AUDIO R | Connect to the composite video and audio output jacks on your camcorder or other video equipment. When Auto is selected for the Video 2 (Component) option in the Setup (MONO)/ AUDIO R settings, the component video function will be preferentially activated (see page 79). |

Rear Panel



| Jack | Description |
|-----------------------------|--|
| 1 CABLE VHF/UHF | RF input that connects to your cable and VHF/UHF antenna signal. |
| 2 CableCARD slot | CableCARD device provides cable subscribers with access to secure, digitally encrypted cable channels — without the need for a set-top box — that will enable you to receive not only standard definition but also high definition television. For more information, see page 30. |
| 3 PC IN 7 | Connect to the video output connector and audio output jack on your personal computer. For details, see page 40. |
| 4 HDMI IN 6 HDMI/ L-AUDIO-R | HDMI (High-Definition Multimedia Interface) provides an uncompressed, all-digital audio/video interface between this TV and any HDMI-equipped audio/video component, such as a set-top box, DVD player, and A/V receiver. HDMI supports enhanced, or high-definition video, plus two-channel digital audio. You can also connect a DVI-equipped device to your TV by using an HDMI-to-DVI cable. |

(Continued)

Introducing the TV

| Jack | Description |
|--|---|
| 5 VIDEO IN 1 S VIDEO | Connects to the S VIDEO output jack of your VCR or other video equipment that has S VIDEO. S VIDEO provides better picture quality than the composite video (6). |
| 6 VIDEO IN 1/3 VIDEO/ L-AUDIO-R | Connect to the composite video and audio output jacks on your VCR or other video component. A third composite video and audio (VIDEO 2) is located on the left side panel of the TV. |
| 7 HD/DVD IN 4/5 (1080i/720p/ 480p/480i)/ L-AUDIO-R | Connect to your DVD player's or digital set-top box's component video (YPbPr) and audio (L/R) jacks. Component video provides better picture quality than the S VIDEO (5) or the composite video (6) connections. |
| 8 AUDIO OUT (VAR/FIX) L/R | Connect to the left and right audio input jacks of your audio or video equipment. You can use these outputs to listen to your TV's audio through your stereo system. |
| 9 DIGITAL AUDIO (OPTICAL) OUT (PCM/DOLBY* DIGITAL) | Connects to the optical audio input of a digital audio component that is PCM/Dolby Digital compatible. |
| 10 AC IN | Connects the supplied AC power cord. |

* Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

Connecting the TV

Overview


Your new LCD projection TV can receive both analog and digital broadcasting signals from antenna, satellite and cable TV.








To display clear crisp pictures, you must connect your TV correctly and choose the correct display format (see “Using the WIDE Button” on page 53). It is strongly recommended to connect the antenna using a 75-ohm coaxial cable to receive optimum picture quality signal. A 300-ohm twin lead cable can be easily affected by radio noise and the like, resulting in signal deterioration. If you use a 300-ohm twin lead cable, keep it as far away as possible from the TV.

Making Video and Audio Connections

The signals that enter your TV and connected devices will need to output in the correct format using the suitable connections. Below are different types of video connectors available these days. Your TV comes with all types of connectors with the exception of the DVI connector but your cable box or satellite receiver may be equipped with this type. When connecting your TV, use the inputs that are available on your devices that provide the best video performance, as described below.

Best Video Performance



| | Connector type | Separate audio connection required |
|---|--|--|
|  | HDMI (High-Definition Multimedia Interface) | No |
|  | DVI (Digital Video Interface) * | Yes  |
|  | Component video (480i/480p/720p/1080i) | |
|  | S VIDEO | |
|  | Composite video | |
|  | RF/Coaxial | No |


* An adapter is necessary when you are connecting a DVI-equipped device to this TV (see page 20).

About Using S VIDEO



If the optional equipment you are connecting has an S VIDEO jack (shown at left), you can use an S VIDEO cable for improved picture quality (compared to an A/V cable). Because S VIDEO carries only the video signal, you also need to connect audio cables for sound, as shown below.

Example of an S VIDEO Connection



About Using HDMI to DVI Adapter


If you are connecting equipment with DVI connector with this TV, you will need to use an adapter. You can use an HDMI-to-DVI cable or an HDMI adapter (not supplied). Both are available from your local electronics store. When you use the adapter, you will also need to use separate audio cables for sound as DVI connector is for video signals only.



HDMI-to-DVI cable



HDMI adapter



Audio cable

Basic Connections

The way in which you connect your TV will vary, depending on how your home receives a signal (antenna and satellite; cable and cable box) and whether or not you plan to connect a VCR.

| <i>If You Are Connecting</i> | <i>See Page</i> |
|--|------------------------|
| <i>Cable System or VHF/UHF</i> | 22 |
| <input type="checkbox"/> No cable box or VCR | |
| <i>Cable Box and Antenna</i> | 23 |
| <input type="checkbox"/> Cable box unscrambles only some channels (usually premium channels) | |
| <input type="checkbox"/> No VCR | |
| <i>Cable Box</i> | 24 |
| <input type="checkbox"/> Cable box unscrambles all channels | |
| <input type="checkbox"/> No VCR | |
| <i>Satellite Receiver</i> | 25 |
| <i>Digital Cable Box or Digital Satellite Receiver</i> | 26 |
| <i>Equipment with HDMI Connection</i> | 27 |
| <i>Equipment with DVI Connection</i> | 28 |
| <i>Equipment with Digital Audio (OPTICAL)</i> | 29 |

If you are connecting a VCR

- See the connections described on pages 34 and 35.

Cable System or VHF/UHF


For best results, use this connection if you:

- Have a cable and/or an antenna.
(This is convenient if you are using a separate rooftop antenna to receive additional channels that are not provided by your cable TV company.)
- Do not have a cable box or VCR. (If you have a cable box, see pages 23 and 24. If you have a VCR, see pages 34 and 35.)

Antenna System

Cable Type **Connect As Shown**

Cable TV (CATV)
and Antenna




Notes on Using This Connection

To Do This...

Do This ...

Switch the TV's input between the cable and antenna

Press ANT to switch back and forth between the TV's VHF/UHF and CABLE inputs.

 **Do not use an indoor antenna, which is especially susceptible to radio noise.**

Cable Box and Antenna


Before connecting a cable box, see “Using CableCARD Device” on page 30.

For best results, use this connection if:

- ❑ Your cable company scrambles some channels, such as premium channels (which requires you to use a cable box), but does not scramble all channels.
- ❑ You do not have a VCR. (If you have a VCR, see pages 34 and 35.)

With this connection you can:

- ❑ Use the TV’s remote control to change channels coming through the cable box to the TV’s CABLE input. (You must first program the remote control for your specific cable box; see “Programming the Remote Control” on page 47.)
- ❑ Use the TV’s remote control to change channels coming directly into the TV’s VHF/UHF input jack.



Notes on Using This Connection

| To Do This ... | Do This ... |
|---|--|
| Use the cable box | Tune the TV to the channel the cable box is set to (usually channel 3 or 4) and then use the cable box to switch channels. |
| Set up the TV remote control to operate the cable box | Program the remote control. See “Programming the Remote Control” on page 47. |
| Activate the remote control to operate the cable box | Press SAT/CABLE (FUNCTION) once, and the SAT/CABLE indicator lights up. |
| Prevent the accidental switching of TV channels | When using the cable box, ensure that the TV remains tuned to the channel that the cable box is set to (usually channel 3 or 4). |
| Switch the TV’s input between the cable box and antenna | Press ANT to switch back and forth between the TV’s VHF/UHF (scrambled channels) and CABLE (unscrambled) inputs. |

Cable Box

Before connecting a cable box, see "Using CableCARD Device" on page 30.

For best results, use this connection if:


- ❑ Your cable company scrambles all channels, which requires you to use a cable box.
- ❑ You do not have a VCR. (If you have a VCR, see pages 34 and 35.)

With this connection you can:

- ❑ Use the TV's remote control to change channels coming through the cable box to the TV's VHF/UHF input jack. (You must first program the remote control for your specific cable box.)

To connect the cable box

- 1** Connect the CATV cable to the cable box's input jack.
- 2** Use a coaxial cable to connect the cable box's output jack to the TV's VHF/UHF input jack.
- 3** Run Auto Program, as described in "Setting Up the Channel List" on pages 32.



Notes on Using This Connection


| To do this... | Do This ... |
|---|--|
| Use the cable box | Tune the TV to the channel the cable box is set to (usually channel 3 or 4) and then use the cable box to switch channels. |
| Set up the TV remote control to operate the cable box | Program the remote control. See "Programming the Remote Control" on page 47. |
| Activate the remote control to operate the cable box | Press SAT/CABLE (FUNCTION) once, and the SAT/CABLE indicator lights up. |
| Prevent the accidental switching of TV channels | When using the cable box, ensure that the TV remains tuned to the channel that the cable box is set to (usually channel 3 or 4). |

Satellite Receiver

Disconnect all power sources before making any connections.

- 1** Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
- 2** Use A/V and S VIDEO cables to connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the TV's AUDIO and S VIDEO IN jacks.
- 3** Use a coaxial cable to connect your cable to the TV's CABLE jack, or your antenna to the TV's VHF/UHF jack.


 **If your satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.**




Digital Cable Box or Digital Satellite Receiver


Disconnect all power sources before making any connections.

- 1 Connect the RF coaxial cable from the CATV or satellite dish to the input of the digital cable box or digital satellite receiver.
- 2 Use a component video cable to connect the digital cable box or satellite receiver's YP_BPr jacks to the TV's Y Pb/C_B Pr/C_R jacks. Use the HD/DVD IN 4 or 5 input.

 **Component video (Y Pb/C_B Pr/C_R) connection is necessary to view 480p, 720p, and 1080i formats. Note that this TV displays all format types of picture in a resolution of 1280 dots x 720 lines.**

- 3 Use an audio cable to connect the digital cable box or satellite receiver's AUDIO OUT jacks to the TV's AUDIO IN jacks.

 **The Y Pb/C_B Pr/C_R jacks do not provide audio, so audio cables must be connected to provide sound.**



Equipment with HDMI Connection


💡 The HDMI jack provides both video and audio signals, so it is not necessary to connect an audio cable.

Use this hookup if:

- Your equipment has a High-Definition Multimedia Interface (HDMI).

Disconnect all power sources before making any connections.


Using an HDMI cable, connect the equipment's HDMI OUT jack to the TV's HDMI IN jack.




Equipment with DVI Connection

Disconnect all power sources before making any connections.

If you are connecting with DVI-HDTV output, you can connect to the TV's HDMI IN jack by using an HDMI-to-DVI cable or an adapter (both not supplied).




 **When using a HDMI-to-DVI cable or an adapter, be sure to connect the DVI output connector first; then connect to the HDMI input on your TV.**

Equipment with Digital Audio (Optical)

Disconnect all power sources before making any connections.

You can use the TV's DIGITAL AUDIO (OPTICAL) OUT jack to connect a digital audio device that is PCM/Dolby Digital compatible, such as an audio amplifier.

Using an optical audio cable, connect the device's OPTICAL IN jack to the TV's DIGITAL AUDIO (OPTICAL) OUT jack.



Using CableCARD Device

The CableCARD device provides cable subscribers with access to digitally encrypted cable channels — without the need for a set-top box — that will enable you to receive not only standard definition but also high definition television. The CableCARD device, which is provided by your cable TV company, is inserted into the TV's rear panel CableCARD slot. After the service is activated with your cable TV company, the card replaces the need for a separate set-top box.

About Using CableCARD Device

If you are planning to use a separate cable box for digital cable TV services, you may be able to receive programming using this TV with the CableCARD device instead — except in the following circumstances:


- ❑ Your cable TV company does not provide CableCARD service in your viewing area.
- ❑ You want to access your cable TV company's interactive or advanced features (such as video-on-demand or, in some cases, pay-per-view). At this time, these services require a bidirectional link, which are only available through the use of a separate set-top box. CableCARD device is currently a unidirectional device only, and cannot provide these advanced services.


Check with your cable TV company for CableCARD service details, limitations, pricing, and availability, all of which are determined by your cable TV company — not Sony.

Activating CableCARD Service


Before you can use CableCARD service, you need to insert the CableCARD device (supplied by your cable TV company) and activate the service, as described below:

- 1** Insert the CableCARD device into the CableCARD slot.



 **CAUTION:** When inserting the CableCARD device, the rear side of the card should face forward. Inserting the CableCARD incorrectly may result in permanent damage to the card and the TV.


- 2** Gently push the card into the slot until it locks into place.

 You can also access information about your CableCARD device in the Applications settings (see page 84).


Removing the CableCARD Device

- 3** After 1-2 minutes, the CableCARD device setup screen is automatically displayed. This screen includes information your cable TV company will request before they can activate your service.
- 4** Follow the displayed instructions: Phone your cable TV company. A representative will guide you through the activation process.
- 5** After your CableCARD device is activated, your cable TV company will download the service information, including the channel list, to the CableCARD device. After the CableCARD device has acquired channels from your cable TV company, the TV tunes to the lowest available channel.

In the event you want to cancel your service, contact your cable TV company.

 **Once the CableCARD device is removed, your TV will no longer decrypt digital cable TV programming services that require CableCARD.**


- 1** Push the eject button on the CableCARD slot to release the card.



- 2** Pull the CableCARD device straight out of the slot to remove it. To install a different CableCARD device, follow the instructions in “Activating CableCARD Service” on page 30.








Setting Up the Channel List

After you finish connecting the TV, you can run the Initial Setup to create a list of available analog and digital channels. The Initial Setup screen appears when you turn on the TV for the first time after hooking it up. If you choose to set up the channels at a later time, select the Auto Program option in the Channel setting to scan available channels (see below).

 **The Initial Setup feature does not apply for installations that use a cable box for all channel selection.**


Using Initial Setup


To run Initial Setup the first time you turn on your TV

- 1 Press  to turn on the TV.
The Initial Setup screen appears.
- 2 Press  or  to highlight the on-screen display language. Then press . The messages “First please connect cable and/or antenna” appears. This may require 50+ minutes for completion and “Start auto program now?” appears.
- 3 Press  or  to highlight “Yes” then press .




Auto Program performed through Initial Setup will automatically create a list of receivable channels from both VHF/UHF antenna and cable TV channels if both sources are connected.

 **Auto Program may take a while (20 to 50 minutes) to complete. A progress bar is displayed while available channels are being scanned. If you cancel the Auto Program before all receivable channels are scanned, you may want to perform the task later (see “To run Auto Program at a later time” below).**

 **If you selected “No” during the Initial Setup, the Initial Setup message will appear each time you turn on the TV until you complete the Auto Program as a reminder.**

To run Auto Program at a later time

- 1 Select Settings in WEGA GATE, and then go to Channel settings.
- 2 Select Auto Program then select Start.

 **Auto Program will create a list of receivable channels for the current input (VHF/UHF antenna or CABLE). You will be required to run Auto Program for each RF input to create a list of available channels from both inputs.**

Connecting Optional Equipment

You can connect a variety of optional equipment to your TV. This section provides some of the individual connections you can make. For multiple connections, please refer to the Quick Setup Guide.

| <i>If You Are Connecting</i> | <i>See Page</i> |
|--|-----------------|
| VCR and Cable | 34 |
| VCR and Cable Box | 35 |
| Two VCRs for Tape Editing | 37 |
| DVD Player with Component Video Connectors | 38 |
| DVD Player with S VIDEO and Audio Connectors | 39 |
| Personal Computer | 40 |
| Camcorder or “PlayStation” | 41 |
| Audio Receiver | 42 |

VCR and Cable


Use this hookup if:

- You have cable TV that does not require a cable box.

Disconnect all power sources before making any connections.

- 1** Connect the CATV cable to the single (input) jack of the splitter.
- 2** Use a coaxial cable to connect one of the output jack of the splitter to the TV's CABLE jack.
- 3** Use a coaxial cable to connect the splitter's other output jack to the VCR's input jack.
- 4** Use A/V and S VIDEO cables to connect the VCR's AUDIO and S VIDEO OUT jacks to the TV's AUDIO and S VIDEO IN jacks.

 **If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.**



VCR and Cable Box

Before connecting a cable box, see “Using CableCARD Device” on page 30.

Use this hookup if:

- ❑ Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box.

With this connection you can:


- ❑ Use the TV’s remote control to change channels on your cable box when the signal is scrambled. To program your Sony remote control to operate your cable box, see “Programming the Remote Control” on page 47.
- ❑ Use the TV’s remote control to change channels on your TV when the signal is not scrambled. Your TV’s tuner provides a better picture quality than the output of your cable box.

Disconnect all power sources before making any connections.

- 1** Connect the CATV cable to the single (input) jack of the splitter.
- 2** Use a coaxial cable to connect one of the output jack of the splitter to the TV’s CABLE jack.
- 3** Use a coaxial cable to connect the splitter’s other output jack to the cable box’s input jack.
- 4** Use a coaxial cable to connect the cable box’s output jack to the VCR’s RF input jack.
- 5** Use an A/V cable to connect the cable box’s A/V output jacks to the TV’s A/V input jacks.
- 6** Use an A/V and S VIDEO cables to connect the VCR’s AUDIO and S VIDEO OUT jacks to the TV’s AUDIO and S VIDEO IN jacks.


 **If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.**

- 7** Run Initial Setup, as described in “Setting Up the Channel List” on page 32.

 **To view scrambled channels, tune the TV to the channel the cable box is set to (usually channel 3 or 4) and then use the cable box to switch channels.**

(Continued)

Connecting the TV



Cables are often color-coded to connectors. Connect red to red, white to white, etc.

If you are connecting a digital cable box, you will need a special bi-directional splitter designed to work with your cable box.

Two VCRs for Tape Editing




Using
S VIDEO jacks?
See page 20.

If you connect two VCRs, you can record from one VCR to the other while using your TV to monitor what is being recorded.

Disconnect all power sources before making any connections.

- 1 Use an A/V cable to connect the playback VCR's A/V output jacks to the recording VCR's A/V input jacks.
- 2 Use an A/V cable to connect the recording VCR's A/V output jacks to the TV's A/V input jacks.

Cables are often color-coded to connectors. Connect red to red, white to white, etc.



- To perform tape editing, set the TV to the video input intended for playback by pressing TV/VIDEO on the remote control.**
- You may need to change the video input on your VCR. See your VCR's operating manual for instructions.**
- If your VCRs have S VIDEO jacks: For best picture quality, use an S VIDEO connection instead of the VIDEO cable (yellow) on your combined A/V cable. Using an S VIDEO cable, connect the playback VCR's S VIDEO OUT jack to the recording VCR's S VIDEO IN jack. S VIDEO does not provide audio, so audio cables must be connected to provide sound.**
- You cannot record signals from equipment connected to the Y Pb/Cb Pr/Cr input.**

DVD Player with Component Video Connectors

Use this hookup if:


- Your DVD player has component (YP_BPr) jacks.


Disconnect all power sources before making any connections.

- 1** Use a component video cable to connect the DVD player's YP_BPr jacks to the TV's Y P_B/C_B Pr/C_R jacks. Use the HD/DVD IN 4 or 5 input.

 **The YP_BPr jacks on your DVD player are sometimes labeled YC_BCr, or Y, B-Y and R-Y. If so, connect the cables to like colors.**

- 2** Use an audio cable to connect the DVD player's AUDIO OUT jacks to the TV's AUDIO IN jacks. Be sure to use the same row of inputs that you used for the video connection (HD/DVD IN 4 or 5).



 **To take advantage of the Wide Mode feature, set the DVD player's aspect ratio to 16:9. For details, refer to the operating instructions supplied with your DVD player.**


DVD Player with S VIDEO and Audio Connectors





Use this hookup if:

- Your DVD player does not have component (YPbPr) jacks.

Disconnect all power sources before making any connections.

- 1** Use an A/V cable to connect the DVD player's AUDIO OUT jacks to the TV's AUDIO IN jacks.
- 2** Use an S VIDEO cable to connect the DVD player's S VIDEO jack to the TV's S VIDEO jack.



-  If your DVD player is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.
-  To watch a DVD, press TV/VIDEO repeatedly to select the DVD input (VIDEO 1 in the illustration). If you have a non-Sony DVD player and want to set up the TV remote control to operate it, you must program the remote control. See "Programming the Remote Control" on page 47.
-  To control DVD functions with the TV remote control, see "Operating a DVD Player or DVD Changer" on page 49.
-  To easily identify equipment connected to the TV, see the instructions for setting up Label Video Inputs on page 79.

Personal Computer


💡 When connecting to an Apple Macintosh computer, use the HD15-HD15 cable to connect PC IN of the TV to video output connector of the computer. For some Apple Macintosh computers, it may be necessary to use an adapter (not supplied). If this is the case, connect the adapter to the computer before connecting the HD15-HD15 cable.

💡 If the picture is noisy or flickering, adjust the Phase and Pitch in the Screen settings on page 71.

To connect a PC (personal computer)

If you connect your PC to the TV, you can watch your personal computer's display on the TV.

When your PC is connected to the TV with the HD15-HD15 cable and optional audio cable, you can view and listen to the PC's video and audio output on the TV.



Camcorder or "PlayStation"



You can connect a camcorder or "PlayStation" to your TV. For easy connection, use VIDEO IN 2 on the left side of the TV. To use the S VIDEO jack instead of the VIDEO jack (yellow), use VIDEO IN 1 on the rear panel of the TV.


To connect a camcorder or "PlayStation" to VIDEO IN 1

Use A/V and S VIDEO cables to connect the AUDIO and S VIDEO OUT jacks on the camcorder or "PlayStation" to the AUDIO and S VIDEO IN jacks on the rear panel of the TV, as shown below.

To connect a camcorder or "PlayStation" to VIDEO IN 2

Select Off in the Video 2 (Component) option in the Setup settings (see page 79). Use an A/V cable to connect the A/V output jacks on the camcorder or "PlayStation" to the A/V input jacks on the left side of the TV.

-  **If your camcorder is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.**
-  **If you have a mono camcorder, connect its audio output jack to the TV's L MONO audio input jack.**





Audio Receiver

For improved sound quality, you may want to play the TV's audio through your stereo system (see page 67).

Disconnect all power sources before making any connections.

Using an audio cable, connect the TV's AUDIO OUT (VAR/FIX) jacks to the audio receiver's audio LINE IN jacks.

 **AUDIO OUT jacks are operable only when the TV's Speaker is set to Off.**



Watching the TV


Overview




The table on the next page describes the buttons on the remote control.

| Topic | Page |
|--|------|
| Inserting Batteries into the Remote Control | 43 |
| Button Descriptions | 44 |
| Programming the Remote Control | 47 |
| Manufacturer's Codes | 48 |
| Using Other Equipment with Your Remote Control | 49 |
| Special Buttons on the Remote Control | 51 |


Inserting Batteries into the Remote Control

Insert two size AA (R6) batteries (supplied) by matching the \oplus and \ominus on the batteries to the diagram inside the battery compartment.






-  To avoid possible damage from battery leakage, remove the batteries if you anticipate the remote control will not be used for an extended period.
-  Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or in high humidity.
-  Your remote control can be programmed to operate most video equipment. (See “Programming the Remote Control” on page 47.)

Button Descriptions



| Button | Description |
|------------------------------|--|
| 1 MUTING | Press to mute the sound. Press again or press VOL + to unmute. |
| 2 TV/VIDEO | Press to cycle through the video equipment connected to your TV's video inputs. |
| 3 FUNCTION Buttons | The FUNCTION button indicator lights up momentarily when pressed to show which external equipment the remote control is operating. When the remote control is set to operate the external equipment, these buttons will operate the equipment you choose. You must first press one of these FUNCTION buttons to operate the corresponding equipment. See page 47 for Programming the Remote Control. |
| 4 0-9, ENT | Press 0-9 to select a channel: the channel changes after 2 seconds. Press ENT to change channels immediately. |
| 5 | Use with 0-9 and ENT buttons to select digital channels (for example, 2.1). |
| 6 JUMP | Press to jump back and forth between two channels. The TV alternates between the current channel and the last channel that was selected. |
| 7 ANT | Press to change between the VHF/UHF input and the CABLE input. |
| 8 SOUND | Press to cycle through different sound settings: Dynamic for enhance treble and bass, Standard for spoken dialog and Custom for flat setting. |
| 9 PICTURE | Press repeatedly to cycle through the available video picture modes: Vivid , Standard , Custom . The video picture modes can be also accessed in the Video menu. For details, see "Selecting Video Options" on page 63. |
| 10 GUIDE | Press to display the TV's program guide. |
| 11 RETURN | Press to return to normal viewing. |
| 12 DVD/VCR Operating Buttons | When FUNCTION is switched on DVR or DVD/VCR, these buttons operate the video equipment you have programmed into the remote control. For details, see "Using Other Equipment with Your Remote Control" on page 49. ⏮ PREV: Press to replay the current program from the previous Chapter Mark (if any) or from the beginning of the live TV cache. ⏮• REPLAY: Press to replay the current program for a set period of time. ⏭ ADVANCE: Press to advance forward a set period of time when playing back a recorded program. ⏭ NEXT: Press to advance forward to the next Chapter Mark (if any) or to live TV when playing back a recorded program. ⏮ (fast reverse): Press to play a program in fast rewind mode. ▶• PLAY: Press to play a program at a normal speed. ▶▶ (fast forward): Press to play a program in fast forward mode. PAUSE: Press to pause playback. ■ STOP: Press to stop the playback of a recorded program. |

The 5 button, CH + button, MTS/SAP and Play button have a tactile dot. Use the tactile dot as a reference when operating the TV.

| Button | Description |
|--|---|
| 13 VISUAL SEARCH | To be used only with your connected external equipment with visual search function. (Non-operable button for TV) |
| 14 VOL +/- | Press to adjust the volume. |
| 15 DVD/VCR Record Buttons | <ul style="list-style-type: none"> ● REC: Press to record. By pressing this button alone will start the recording. ▮▮ REC PAUSE: Press to pause the recording. ■ REC STOP: Press to stop the recording. |
| 16 TOP MENU | Press to display the disc menu from your connected DVD player. |
| 17 MENU | Press to display the disc menu from your connected DVD player. |
| 18 POWER | Press to turn on/off the external equipment selected from the FUNCTION buttons [3]. |
| 19 TV POWER | Press to turn on/off the TV. |
| 20 MTS/SAP | Press repeatedly to cycle through the Multi-channel TV Sound (MTS) options: Stereo, Auto SAP (Second Audio Program), and Mono. The MTS setting can be also accessed in the Audio setting. For more details, see “Selecting Audio Options” on page 66. |
| 21 FREEZE | Press to freeze the current picture. Press again to restore the picture. For details, see “Using the FREEZE Button” on page 54. |
| 22 TV/SAT/SUR | <p>TV/SAT: While in SAT/CABLE FUNCTION, press to switch between the satellite receiver and antenna.</p> <p>SUR: Press SUR (Surround Sound) repeatedly to step through the available audio effect models: TruSurround XT, Simulated, Off.</p> |
| 23 WIDE | Press repeatedly to step through the Wide Screen Mode setting: Wide Zoom, Normal, Full and Zoom. The Wide Screen Mode setting can be also accessed in the Screen setting. For details, see “Using the WIDE Button” on page 53. |
| 24 DISPLAY | Press once to display channel number, label, current time and other information. Press again to turn Display off. See page 83 for details on setting the time. |
| 25  | Press  to move the on-screen cursor. To select an item, press  . |
| 26 TOOLS | To be used only with your connected external equipment that supports this TOOLS function. (Non-operable button for TV) |
| 27 WEGA GATE | <p>Press to access the following through the WEGA GATE:</p> <ul style="list-style-type: none"> • Watch TV (see page 58) • Select channels from the Favorites Channels you stored (see page 57) • View signals from external equipment such as DVD, VCR and others (see page 59). • Adjust or customize TV settings (see Using the Settings on page 59). |
| 28 CH +/- | Press to scan through channels. To scan quickly through channels, press and hold down either +/- button. |

(Continued)

Watching the TV

| <i>Button</i> | <i>Description</i> |
|---------------|---|
| 29 F1 | Press to select the function of connected components. For details, see “Using Other Equipment with Your Remote Control” on page 49. |
| 30 F2 | Press to select the function of connected components. For details, see “Using Other Equipment with Your Remote Control” on page 49. |







Programming the Remote Control

The remote control is preset to operate Sony brand video equipment.


| Sony Equipment | Programmable Code Number |
|----------------|-------------------------------|
| DVR | 772 |
| DVD/VCR | 601 (Sony Dream System) |
| SAT/CABLE | 801 (Sony Satellite Receiver) |




Follow the steps below to program your TV's remote control to operate the non-Sony video equipment.


Find the three-digit code for your equipment from the "Manufacturer's Codes" listed on page 48. If more than one code number is listed, try entering from the code listed first.

- Press and hold the , , or  FUNCTION button you want to program on the remote control and press the  button simultaneously. The selected FUNCTION button (DVR, DVD/VCR or SAT/CABLE) will flash.
- Enter the three-digit manufacturer's code number using the  buttons while the button is lit. If code is not entered within 10 seconds, you must perform step 1 again.
- Press  button. When the programming is correct, the selected FUNCTION button will flash twice, and when not, flashes five times.

To check if the code works

Aim your TV's remote control at the equipment, and press the green  button. If the equipment turns on and off, the programming is completed. If not, try the next code listed.

-  **If no code is input within the above specified time, or an invalid or incorrect code number is input, the remote control automatically goes back to the previous setting.**
-  **In some cases, you may not be able to program your remote control to operate other equipment. In such cases, use the equipment's own remote control.**
-  **Using dead batteries or removing the batteries may cause the programmable codes to be lost and revert back to factory settings. Reprogramming the codes may be necessary.**



Watching the TV

Manufacturer's Codes

DVD Players

| Manufacturer | Code |
|------------------|----------|
| Sony | 751 |
| General Electric | 755 |
| Hitachi | 758 |
| JVC | 756 |
| Magnavox | 757 |
| Mitsubishi | 761 |
| Panasonic | 753 |
| Philips | 757 |
| Pioneer | 752, 778 |
| RCA/PROSCAN | 755 |
| Samsung | 758 |
| Toshiba | 754 |
| Zenith | 760 |

DVD Changers

| Manufacturer | Code |
|--------------|------|
| Sony | 765 |
| Panasonic | 766 |

DVD/VCR Combo Units

| Manufacturer | Code |
|--------------|------|
| Sony | 767 |
| Broksonic | 776 |
| JVC | 775 |
| Panasonic | 777 |
| Samsung | 774 |
| Toshiba | 773 |
| Zenith | 768 |

HDD/DVD Combo Units

| Manufacturer | Code |
|--------------|---------------|
| Sony | 772, 771, 770 |

5.1ch DVD AV System

| Manufacturer | Code |
|--------------|--------------------|
| Sony (DAV) | 601, 602, 603, 604 |

AV Receivers

| Manufacturer | Code |
|--------------|------|
| Sony | 764 |

VCRs

| Manufacturer | Code |
|-------------------|---------------|
| Sony | 301, 302, 303 |
| Admiral (M. Ward) | 327 |
| Aiwa* | 338, 344 |
| Audio Dynamic | 314, 337 |
| Broksonic | 319, 317 |
| Canon | 309, 308 |

| Manufacturer | Code |
|------------------|---|
| Citizen | 332 |
| Craig | 302, 332 |
| Curtis Mathes | 304, 338, 309 |
| Daewoo | 341, 312, 309 |
| DBX | 314, 336, 337 |
| Dimensia | 304 |
| Emerson | 319, 320, 316, 317, 318, 341 |
| Fisher | 330, 335 |
| Funai | 338 |
| General Electric | 329, 304, 309 |
| Go Video | 322, 339, 340 |
| Goldstar | 332 |
| Hitachi | 306, 304, 305, 338 |
| Instant Replay | 309, 308 |
| JC Penney | 309, 305, 304, 330, 314, 336, 337 |
| JVC | 314, 336, 337, 345, 346, 347 |
| Kenwood | 314, 336, 332, 337 |
| LG | 332 |
| LXI (SEARS) | 332, 305, 330, 335, 338 |
| Magnavox | 308, 309, 310 |
| Marantz | 314, 336, 337 |
| Marta | 332 |
| Memorex | 309, 335 |
| Minolta | 305, 304 |
| Mitsubishi/MGA | 323, 324, 325, 326 |
| Multitech | 325, 338, 321 |
| NEC | 314, 336, 337 |
| Olympic | 309, 308 |
| Optimus | 327 |
| Orion | 317 |
| Panasonic | 308, 309, 306, 307 |
| Pentax | 305, 304 |
| Philco | 308, 309 |
| Philips | 308, 309, 310 |
| Pioneer | 308 |
| Quasar | 308, 309, 306 |
| RCA/PROSCAN | 304, 305, 308, 309, 311, 312, 313, 310, 329 |
| Realistic | 309, 330, 328, 335, 324, 338 |
| Sansui | 314 |
| Samsung | 322, 313, 321 |
| Sanyo | 330, 335 |
| Scott | 312, 313, 321, 335, 323, 324, 325, 326 |

| Manufacturer | Code |
|--------------------------|-------------------------|
| Sharp | 327, 328 |
| Signature 2000 (M. Ward) | 338, 327 |
| SV2000 | 338 |
| Sylvania | 308, 309, 338, 310 |
| Symphonic | 338 |
| Tashiro | 332 |
| Tatung | 314, 336, 337 |
| Teac | 314, 336, 338, 337 |
| Technics | 309, 308 |
| Toshiba | 312, 311 |
| Wards | 327, 328, 335, 331, 332 |
| Yamaha | 314, 330, 336, 337 |
| Zenith | 331 |

Cable Boxes

| Manufacturer | Code |
|--------------------------------|--|
| Sony | 230 |
| Hamlin/Regal | 222, 223, 224, 225, 226 |
| Jerrold/General Inst./Motorola | 201, 202, 203, 204, 205, 206, 207, 208, 218, 222 |
| Oak | 227, 228, 229 |
| Panasonic | 219, 220, 221 |
| Pioneer | 211, 214, 215 |
| Scientific Atlanta | 209, 210, 211 |
| Tocom | 216, 217 |
| Zenith | 212, 213 |


Satellite Receivers

| Manufacturer | Code |
|------------------|----------|
| Sony | 801 |
| Dish Network | 810 |
| Echostar | 810 |
| General Electric | 802 |
| Hitachi | 805 |
| Hughes | 804 |
| Mitsubishi | 809 |
| Panasonic | 803 |
| Philips | 811 |
| RCA/PROSCAN | 802, 808 |
| Toshiba | 806, 807 |
| Samsung | 812 |

* If an Aiwa VCR does not work even though you enter the code for Aiwa, enter the code for Sony instead.

Using Other Equipment with Your Remote Control

To operate other equipment connected to your TV, first turn to page 48 and program the necessary code. For operating video equipment, press TV/VIDEO repeatedly until you see the video input on the screen for your connected equipment. Remote control tips are provided below.

 **Some functions cannot be operated depending on the equipment. In that case, operate by the remote control supplied with the equipment.**

Operating a Cable Box

| To Do This ... | Press ... |
|--|----------------------|
| Activate the remote control to operate the cable box | SAT/CABLE (FUNCTION) |
| Turn on/off | POWER |

Operating a Satellite Receiver

| To Do This ... | Press ... |
|---|----------------------|
| Activate the remote control to operate the satellite receiver | SAT/CABLE (FUNCTION) |
| Turn on/off | POWER |
| Select a channel | 0-9, ENT |
| Change channels | CH +/- |
| Back to previous channel | JUMP |
| Display channel number | DISPLAY |

Operating a VCR

| To Do This ... | Press ... |
|--|--------------------|
| Activate the remote control to operate the VCR | DVD/VCR (FUNCTION) |
| Turn on/off | POWER |
| Change channels | CH +/- |
| Record | ● |
| Play | ▷ |
| Stop | ■ |

Operating a DVD Player or DVD Changer

| To Do This ... | Press ... |
|--|---|
| Activate the remote control to operate the DVD | DVD/VCR (FUNCTION) |
| Turn on/off | POWER |
| If you have a DVD changer, to skip disc | F1 |
| Play | ▷ |
| Stop | ■ |
| Pause | ⏸ (press again to resume normal playback) |

| To Do This ... | Press ... |
|--------------------------|-----------|
| Select a channel | 0-9, ENT |
| Change channels | CH +/- |
| Back to previous channel | JUMP |

| To Do This ... | Press ... |
|--|-----------|
| Display SAT Guide | GUIDE |
| Display SAT Menu | MENU |
| Move highlight (cursor) | ⬆ ⬇ ⬇ ⬆ |
| Select item | ⊕ |
| Switch between the TV and satellite broadcasts | TV/SAT |

| To Do This ... | Press ... |
|--|--|
| Fast forward | ⏩ |
| Rewind the tape | ⏮ |
| Pause | ⏸ (press again to resume normal playback) |
| Search the picture forward or backward | ⏩ or ⏮ during playback (release to resume normal playback) |

| To Do This ... | Press ... |
|---|--|
| Step through different tracks of the disc | ⏮ to fast reverse or ⏩ to fast forward the disc when pressed during playback |
| Step through different chapters of the disc | ⏪ to step forward or ⏩ to step backward |
| Select a track directly | 0-9, ENT |
| Display the disc menu | MENU |
| Display the top menu | TOP MENU |
| Operate the DVD menu | ⬆ ⬇ ⬇ ⬆, ⊕ |

(Continued)

Watching the TV

Operating a 5.1ch DVD AV System (Sony DAV)

| To Do This ... | Press ... |
|--|--------------------|
| Activate the remote control to operate the DVD | DVD/VCR (FUNCTION) |
| Turn on/off | POWER |
| Select other equipment connected to the DAV | F1 |
| Disk skip | F2 |
| Display the top menu | TOP MENU |
| Display the disc menu | MENU |

Operating a DVD/VCR Combo Unit

| To Do This ... | Press ... |
|--|--------------------|
| Activate the remote control to operate the DVD/VCR | DVD/VCR (FUNCTION) |
| Turn on/off | POWER |
| Select the DVD | F 1 |
| Select the VCR | F 2 |
| Display the top menu | TOP MENU |
| Display the disc menu | MENU |
| Play | ▷ |
| Stop | ■ |
| Pause | ⏸ |

Operating a HDD/DVD Combo Unit

| To Do This ... | Press ... |
|--|--------------------------|
| Activate the remote control to operate the DVD/HDD | DVR (FUNCTION) |
| Turn on/off | POWER |
| Select the HDD | F 1 |
| Select the DVD | F 2 |
| Play | ▷ |
| Stop | ■ |
| Pause | ⏸ |
| Search the picture forward or backward | ▶▶ or ◀◀ during playback |

Operating an AV Receiver

| To Do This ... | Press ... |
|---|-----------------|
| Turn on/off | POWER |
| Master volume | VOL +/-, MUTING |
| Select other input connected to AV receiver | F1 |

| To Do This ... | Press ... |
|--|--------------------------|
| Play | ▷ |
| Stop | ■ |
| Pause | ⏸ |
| Search the picture forward or backward | ▶▶ or ◀◀ during playback |
| Specify the previous chapter/track | ⏮ |
| Specify the next chapter/track | ⏭ |
| Move highlight (cursor) | ⬆ ⬇ ⬇ ⬆ |
| Select item | ⊕ |
| Master volume | VOL +/-, MUTING |

| To Do This ... | Press ... |
|--|----------------------------------|
| Search the picture forward or backward | ▶▶ or ◀◀ during playback |
| Replay | ◀• |
| Advance | •▶ |
| Move highlight (cursor) and select (DVD) | ⬆ ⬇ ⬇ ⬆ ⊕ |
| Record (VCR) | ● |
| Change channels (VCR) | CH +/- or 0-9, ENT (using tuner) |
| Adjust tracking (VCR) | CH +/- (during tape playback) |

| To Do This ... | Press ... |
|------------------------------------|--------------|
| Move highlight (cursor) and select | ⬆ ⬇ ⬇ ⬆ ⊕ |
| Record | ● |
| Specify the previous chapter/track | ⏮ |
| Specify the next chapter/track | ⏭ |
| Replay | ◀• |
| Advance | •▶ |
| Display the disc menu | MENU |
| Display the top menu | TOP MENU |


Special Buttons on the Remote Control

This TV comes with convenient features that can be accessed directly by pressing their buttons on your remote control.

Using the **GUIDE** Button

This TV is equipped to show program information if it is available from the station. The Program Guide lets you review program information, and select both analog and digital channels.


To display the Program Guide:


- 1** Tune your TV to a channel by using the 0-9, , and ENT buttons.
- 2** Press GUIDE on the TV's remote control. The Program Guide will appear with the currently selected program showing in the background.

Channel number, call letters, etc.

Program title and description, program duration, time remaining, rating information, closed-caption availability, etc.

Selectable channel list.





 **Program information in the guide is provided by the broadcasters. As a result, it may sometimes include only the channel number, without a program title or description.**

(Continued)

Using the Program Guide

The Program Guide allows you to select the channels from a drop down list. The Guide also provides information about the current program being shown on each channel.



 **Subchannels are additional channels of programming broadcast simultaneously. For example, channel 4 might include three subchannels (4.1, 4.2, 4.3) that are showing programs at the same time.**


Using the Program Options Setting

The Program Options setting allows you to customize the program settings on the currently tuned channel.

| Option | Description |
|-------------------------------------|--|
| Alternate Video (When available) | Each program has a main video stream (the video that you see when the channel is first tuned), and may have alternate video streams. This option allows you to switch among these alternate video streams. |
| Alternate Audio (When available) | Each program has a main audio stream (the audio you hear when the channel is first tuned), and may have alternate audio streams. This option allows you to switch among these alternate audio streams (e.g., for different languages). |

Using the WIDE Button

Wide screen mode lets you watch 4:3 normal broadcasts in several wide screen modes (16:9 aspect ratio).




💡 When the TV receives a 720p or 1080i signal that is 4:3 aspect ratio picture with a black bar at each side, Full returns the picture to its original size.

💡 You can also access the Wide Mode settings in the Screen settings. For details, see page 69.


🔧 When the TV receives a 720p or 1080i signal, Normal cannot be selected.

Changing the wide screen mode




Using the JUMP Button

The JUMP button allows you to jump back and forth between the current channel and the last channel that was selected.




Using the FREEZE Button


The FREEZE button allows you to temporarily capture a program's picture. You can use this feature to write down information such as phone numbers, recipes, etc. To cancel FREEZE and return to normal viewing, press the FREEZE button again.




Introducing WEGA GATE


Overview of WEGA GATE

WEGA GATE provides one button access for controlling your TV. It enables you to perform a variety of tasks intuitively with a control panel on the screen rather than a variety of remote control button presses. When you press the  button, you can select from basic TV function: selecting from Favorite Channels, watching TV, viewing external equipment signals or adjusting TV settings.



- 1 Press WEGA GATE on the remote. WEGA GATE control panel appears.








- 2 Press  to highlight the item.

- 3 Press  to select.

- 4 Press  to exit.

The WEGA GATE screen gives you access to the following items:

| <i>Icon</i> | <i>Description</i> |
|---|---|
|  Favorites | The Favorites feature lets you select programs from a list of up to 16 favorite channels that you specify. For details, see page 57. |
|  Cable | The Cable feature takes you to the most recently viewed channel on the cable input. When tuned to the channel, the Program Banner and Channel number will be displayed. When this feature is active, ○ is displayed to the left of the icon. |
|  Antenna | The Antenna feature takes you to the most recently viewed channel on the antenna input. When tuned to the channel, the Program Banner and Channel number will be displayed. When this feature is active, ○ is displayed to the left of the icon. |
|  External Inputs | The External Inputs feature lets you select equipment that is connected to your TV, such as a DVD player. You can assign a label to your equipment or skip unused inputs conveniently. For details, see page 59. When this feature is active, ○ is displayed to the left of the icon. |
|  Settings | The Settings feature lets you adjust the Video, Audio, Screen, Channel, Parental Lock, Setup or Applications settings. For details, see page 59. |

Navigating and Selecting Items

Use your remote control to navigate through WEGA GATE and the settings.


| To Do This ... | Press ... |
|--|--------------------------------------|
| Display WEGA GATE control panel | Press WEGA GATE. |
| Display Settings | Press WEGA GATE and select Settings. |
| Move through Settings | Press ↑ ↓ ← → . |
| Select an option to change | Press ⊕ . |
| Move back to upper layer | Press RETURN. |
| Select (confirm) changed setting | Press ⊕ . |
| Exit WEGA GATE control panel or Settings | Press WEGA GATE. |

Using Favorites in WEGA GATE

The Favorites feature lets you select programs from a list of up to 16 favorite channels that you specify. You can create a list using the Add to Favorites option.

- 1 Select Favorites from the WEGA GATE control panel and press **⊕**.

The Favorite Channels list appears. Make your selection.





- 2 Press **↑/↓** to highlight the desired channel and press **⊕**.
 - To add the current channel to the list of Favorite Channels, highlight Add to Favorites and press **⊕**.
 - When the Favorite Channels list is full, select Edit Favorites to remove a channel from the list or go to the Channel settings and select Favorite Channels then edit the channel.

Using Cable in WEGA GATE

The Cable feature takes you to the most recently viewed channel on the cable input. When tuned to the channel, the Program Banner and Channel number will be displayed.

Select Cable from the WEGA GATE control panel and press .




 **If you have not completed the initial channel setup (see page 32) both Cable and Antenna will tune to the lowest channel number. To run Initial Setup see page 72.**

Using Antenna in WEGA GATE

The Antenna feature takes you to the most recently viewed channel on the antenna input. When tuned to the channel, the Program Banner and Channel number will be displayed.

Select Antenna from the WEGA GATE control panel and press .




 **If you have not completed the initial channel setup (see page 32) both Cable and Antenna will tune to the lowest channel number. To run Initial Setup see page 72.**




Using External Inputs in WEGA GATE

The External Inputs feature lets you view from a selected external input connected to your TV. You can assign a label or skip over unused inputs by selecting **Edit Video Labels**. Input label assignment can also be done by going to Setup settings and select **Label Video Inputs** (see page 79).

- 1 Select **External Inputs** from the WEGA GATE control panel and press .

The External Inputs list appears. Make your selection.



- 2 Press **↑/↓** to highlight the desired external input and press .



Using Settings in WEGA GATE




The **Settings** feature lets you enter to the settings screen where most of advanced settings and adjustments are performed. See “Overview ” on page 61.

Using the Settings

Overview





The Settings give you access to the following features:

(Depending on the signal tuned, you may see a different Setting options on your screen. Settings displayed here are with the 720p signal.)

| Settings | Allows you to set/change | |
|---|---|---|
| <p>Video</p>  | <ul style="list-style-type: none"> Picture Mode (page 63) Reset (page 63) Iris (page 63) Picture (page 63) Brightness (page 63) Color (page 63) Hue (page 63) Color Temp. (page 64) Sharpness (page 64) Noise Reduction (page 64) | <ul style="list-style-type: none"> DRC Mode (page 64) DRC Palette (page 64) Advanced Video (page 65) |
| <p>Audio</p>  | <ul style="list-style-type: none"> Sound Mode (page 66) Reset (page 66) Treble (page 66) Bass (page 66) Balance (page 66) Steady Sound (page 66) Volume Offset (page 66) Effect (page 66) BBE (page 66) | <ul style="list-style-type: none"> MTS (page 67) Speaker (page 67) Audio Out (page 67) A/V Sync (page 67) |
| <p>Screen</p>  | <ul style="list-style-type: none"> Wide Mode (page 69) Game Picture (page 69) 4:3 Default (page 70) Display Area (page 70) Vertical Center (page 70) Vertical Size (page 70) | |

(Continued)

Using the Settings

| Settings | Allows you to set/change |
|---|--|
| <p>Channel</p>  | <ul style="list-style-type: none">Favorite Channels (page 72)Digital Channels (page 72)Auto Program (page 72)Show/Hide Channels (page 72)Label Channels (page 73) |
| <p>Parental Lock</p>  | <ul style="list-style-type: none">Parental Lock (page 74)Change Password (page 75)Select Country (page 75) |
| <p>Setup</p>  | <ul style="list-style-type: none">Caption Vision (page 78)Info Banner (page 78)Game Mode (page 78)Label Video Inputs (page 79)Language (page 79)Video 2 (Component) (page 79)Menu Color (page 79)Image Shift (page 79)High Altitude (page 80)CineMotion (page 80) |
| <p>Applications</p>  | <ul style="list-style-type: none">Clock/Timers (page 83)Diagnostics (page 84)CableCARD (page 84) |

Accessing the Video Settings

1. Press WEGA GATE.....




2. Select Settings.....



3. Highlight.....



4. Press to select.....




To highlight an option and to change settings, press \uparrow \downarrow \leftarrow \rightarrow .



Press \odot to confirm the selection.

To exit the Video, press .


Selecting Video Options

 To quickly and easily change from one Picture Mode to another, use PICTURE on the remote control.

The Video settings include the following options:

| Option | Description |
|--------------|--|
| Picture Mode | <p>Vivid Select for enhanced picture contrast and sharpness.</p> <p>Standard Select for standard picture settings. Recommended for home entertainment.</p> <p>Customized picture viewing Custom Select to display a picture with minimum enhancements.</p> |
| | <p> You can alter the Video settings (Picture, Brightness, Color, etc.) for each Picture Mode and each video input.</p> <p> You may set up a Picture Mode (Vivid, Standard, Custom) independently for each Video input (Video 1-Video 6, including the Antenna input). Your Picture Mode settings are automatically saved after each selection. This allows you to customize the Picture Mode setting for each type of signal source.</p> |
| Reset | Select OK to reset all settings and adjustments to the default setting (except for Advanced Video). |
| Iris | Adjust the contrast levels. |
| Picture | Adjust to increase picture contrast and deepen the color or decrease picture contrast and soften the color. |
| Brightness | Adjust to brighten or darken the picture. |
| Color | Adjust to increase or decrease color intensity. |
| Hue | Adjust to increase or decrease the green tones. |

(Continued)


| Option | Description |
|--|--|
| Color Temp. <i>White intensity adjustment</i> | Cool Select to give the white colors a blue tint. |
| | Neutral Select to give the white colors a neutral tint. |
| | Warm 1, 2 When selected Custom in Picture Mode, select to give the white colors a red tint. |
| Sharpness | Adjust to sharpen or soften the picture. |
| Noise Reduction | Select to reduce the noise level of connected equipment. This also reduces the noise level to the signal from the VHF/UHF jack. Select from Auto, High, Medium, Low and Off. |
| When ATSC or Component is in use, Auto is not available. | |
| DRC Mode | High Density Creates a high-resolution picture with 4 x density, for high quality sources (i.e., DVD player, satellite receiver). |
| | Progressive Recommended for moving pictures. |
| | Off |
| DRC Mode is not available when Game Mode is On or using the Freeze feature; also not available when watching 480p, 720p or 1080i sources. | |
| DRC Palette | <p>Custom Allows you to customize the level of detail (Reality) and smoothness (Clarity) for up to three input sources. For example, you can create one Custom setting to optimize your cable input's picture, and create another to optimize your DVD player's picture. You can switch among the three Custom settings.</p> <ol style="list-style-type: none"> Press the arrow buttons to highlight Custom then press . The DRC palette appears.  <ol style="list-style-type: none"> Press the arrow buttons to adjust the position of the marker (●). As you move the ● higher along the Reality axis, the picture becomes more detailed. As you move the ● to the right along the Clarity axis, the picture becomes smoother. To save the setting, press . |
| DRC Palette is not available when Game Mode is On, Noise Reduction is set to Auto, DRC Mode is Off or using the Freeze feature; also not available when watching 480p, 720p or 1080i sources. | |


| Option | Description |
|---|--|
| Advanced Video <i>Available in "Custom Picture Mode"</i> | Program Select Program to choose among the options: Black Corrector (High/Medium/Low/Off), Advanced Iris (High/Medium/Low/Off), Gamma (Max/High/Medium/Low/Off), Clear White (High/Low/Off), Live Color (High/Medium/Low/Off). |

Selecting PC Video Options

To display the PC screen:

Press TV/VIDEO repeatedly on the remote control until VIDEO 7 (PC) appears.








 You can change the settings for the PC input while the TV is displaying the PC screen.

The PC Input Video setting includes the following options:

| Option | Description |
|--------------|---|
| Display Mode | Video Select to view video images. |
| | Text Select to view text, charts or tables. |
| Reset | Select to restore the factory default settings. |
| Iris | Select to adjust the contrast levels. |
| Picture | Adjust to increase or decrease picture contrast. |
| Brightness | Adjust to brighten or darken the picture. |
| Color Temp. | Choose from four color temperatures: |
| | Cool Select to give the white colors a blue tint. |
| | Neutral Select to give the white colors a neutral tint. |
| | Warm 1, 2 Select to give the white colors a red tint. |

Accessing the Audio Settings

1. Press WEGA GATE..... 
2. Select Settings..... 
3. Highlight..... 
4. Press to select..... 





To highlight an option and to change settings, press **↑ ↓ ← →**.


Press **Enter** to confirm the selection.



To exit the Audio, press **WEGA GATE**.

Selecting Audio Options

-  Sound Mode settings are independent of settings in the Treble/Bass options.
-  TruSurround XT attempts to create the same surround effect produced by a multichannel system using the left and right speakers.

The Audio settings include the following options:


| Option | Description |
|---------------|---|
| Sound Mode | Dynamic Select to enhance treble and bass. |
| | Standard Suitable for spoken dialog. |
| | Custom Flat setting. |
| Reset | Reset the following options to the default setting: Treble, Bass, Balance, Steady Sound, Volume Offset, Effect and BBE. |
| Treble | Adjust to increase or decrease higher-pitched sounds. |
| Bass | Adjust to increase or decrease lower-pitched sounds. |
| Balance | Adjust to emphasize left or right speaker balance. |
| Steady Sound | On Select to stabilize the volume across all programs and commercials. |
| | Off Select to turn off Steady Sound. |
| Volume Offset | Adjust to increase or decrease the sound level of the current input (TV or video input) relative to other inputs. |
| Effect | TruSurround XT Select for surround sound (for stereo programs only). |
| | Simulated Adds a surround-like effect to mono programs. |
| |  Simulated uses SRS 3D MONO. |
| | Off Normal stereo or mono reception. |
| BBE | Select to give sound more impact by compensating for phase effects in speakers. Select from High, Low, and Off. |


| Option | Description |
|--|--|
| MTS <i>Enjoy stereo, bilingual and mono programs</i> | Stereo Select for stereo reception when viewing a program broadcast in stereo. |
| | Auto SAP Select to automatically switch to second audio programs when a signal is received. (If no SAP signal is present, the TV remains in Stereo mode.) |
| | Mono Select for mono reception. (Use to reduce noise during weak stereo broadcasts.) |
|  MTS is available only for analog programs. | |
| Speaker | On Select to turn on the TV speakers. |
| | Off Select to turn off the TV speakers and listen to the TV's sound only through your external audio system speakers. |
|  The MUTING button on your remote control is available when Audio Out is set to Variable, and becomes nonfunctional when set to Fixed. | |
| Audio Out <i>Easy control of volume adjustments</i> | This option can be set only when the Speaker option is set to Off . |
| | Variable The TV's speakers are turned off and the audio output from your audio system can still be controlled by the TV's remote control. |
| | Fixed The TV's speakers are turned off, and the audio output of the TV is fixed. Use your audio receiver's volume control to adjust the volume (and other settings) through your audio system. |
| A/V Sync | Off/1/2/3 Use this option to make adjustments to audio and video synchronization when you have external equipment connected to DIGITAL AUDIO (OPTICAL) OUT of the TV. Select Off (factory default setting) to make no adjustments. Select 1, 2 or 3 to adjust so that the video and audio from your connected external equipment are in synchronized. |

Selecting PC Audio Options

To display the PC screen:

Press TV/VIDEO repeatedly on the remote control until VIDEO 7 (PC) appears.



 You can change the settings for the PC input while the TV is displaying the PC screen.

The PC Input Audio setting includes the following options:

| Option | Description |
|---|---|
| Sound Mode | Dynamic Select to enhance treble and bass. |
| | Standard Suitable for spoken dialog. |
| | Custom Flat setting. |
| Reset | Select to restore the factory default settings. |
| Treble | Adjust to increase or decrease higher-pitched sounds. |
| Bass | Adjust to increase or decrease lower-pitched sounds. |
| Balance | Adjust to emphasize left or right speaker balance. |
| Effect | TruSurround XT Select for surround sound (for stereo programs only). |
| | Simulated Adds a surround-like effect to mono programs. |
| | Off Normal stereo or mono reception. |
| Speaker | On Select to turn on the TV speakers. |
| | Off Select to turn off the TV speakers and listen to the TV's sound only through your external audio system speakers. |
| Audio Out | This option can be set only when the Speaker option is set to Off . |
| <i>Easy control of volume adjustments</i> | Variable The TV's speakers are turned off, but the audio output from your audio system can still be controlled by the TV's remote control. |
| | Fixed The TV's speakers are turned off and the audio output of the TV is fixed. Use your audio receiver's volume control to adjust the volume (and other settings) through your audio system. |



Accessing the Screen Settings

1. Press WEGA GATE.....




2. Select Settings.....



3. Highlight.....



4. Press to select.....




To highlight an option and to change settings, press \uparrow \downarrow \leftarrow \rightarrow .


Press \odot to confirm the selection.


To exit the Screen, press .

Selecting Screen Options

 Wide Mode is unavailable while in Freeze (page 54).

The Screen settings include the following options:

| Option | Description |
|---|---|
| Wide Mode | Wide Zoom |
| <i>Select a screen mode to use for 4:3 sources.</i> | Select to enlarge the 4:3 picture, to fill the 16:9 screen, keeping the original image as much as possible. |
| | Normal |
| | Select to return the 4:3 picture to its original size and aspect ratio. |
| |  Normal is not available when you are watching 720p or 1080i sources. |
| | Full |
| | Select to enlarge the 4:3 picture horizontally only, to fill the display area. |
| | Zoom |
| | Select to proportionally enlarge 1080i and 720p sources, For 480p and 480i sources, Zoom will vertically stretch the image to fill the screen. |

 **To change from one Wide Mode setting to another, use the WIDE button on the remote control (see page 53).**

Game Picture Allows you to move the position of the picture left and right in the window. (This feature also allows you to adjust the picture from any connected equipment.) Select while watching the picture to be adjusted. The TV stores the position in memory for each input. Press \leftarrow or \rightarrow and press \odot to choose a correction between +5 and -5.

 **Not available in Full and Normal mode when sources are in 720p or 1080i.**

(Continued)

Using the Settings

💡 If 4:3 Default is set to anything but Off, the Wide Mode setting changes only for the current channel. When you change channels (or inputs), Wide Mode is automatically replaced with the 4:3 Default setting. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off.


| Option | Description | |
|--|---|--|
| 4:3 Default <i>Select the default screen mode to use for 4:3 sources.</i> | Wide Zoom | Select to enlarge the 4:3 picture, to fill the 16:9 screen, keeping the original image as much as possible. |
| | Normal | Select to return the 4:3 picture to normal mode. |
| | Full | Select to enlarge the 4:3 picture horizontally only, to fill the display area. |
| | Zoom | Select to enlarge the picture horizontally and vertically to an equal aspect ratio that fills the wide screen. |
| | Off | Select to continue using the current screen mode setting when the channel or input is changed. |
| Display Area | Select Normal to return to the default display area. Select -1 or -2 to keep the edge of the picture out of screen. | |
| Vertical Center | Allows you to move the position of the picture up and down in the window. (Available only in Zoom mode.) Press ▲ or ▼ and press ⊕ to choose a correction between +5 and -5. | |
| Vertical Size | Allows you to adjust the vertical size of the picture. (Available only in Zoom mode.) Press ▲ or ▼ and press ⊕ to choose a correction between +5 and -5. | |

Selecting PC Screen Options

💡 When there is no signal input, all settings are not available.

To display the PC screen:

Press TV/VIDEO repeatedly on the remote control until VIDEO 7 (PC) appears.







🔧 You can change the settings for the PC input while the TV is displaying the PC screen.


The PC Input Screen setting includes the following options:

💡 Select Zoom in the Wide Mode option to display movies and other content on DVD, using the entire viewable area of the screen.

| Option | Description | |
|---------------------|--|--|
| Wide Mode | Normal | Select to display the picture in its original size. |
| | Full 1 | Select to enlarge the picture to fill the display area, keeping its original horizontal-to-vertical ratio. |
| | 🔧 Full 2 | Select to enlarge the picture to fill the display area. |
| | 🔧 Full 2 | A black frame will appear on the surrounding of the picture. |
| Zoom | Select to enlarge the picture horizontally and vertically to an equal aspect ratio that fills the wide screen. | |
| Auto Adjustment | Select to automatically adjust the display position of the picture when the TV receives an input signal from the connected PC. Note that Auto Adjustment may not work well with certain input signals. In such cases, manually adjust the options below. | |
| Phase | Select to adjust the phase when the screen flickers. | |
| Pitch | Select to adjust the pitch when the picture has unwanted vertical stripes. | |
| Horizontal Center | Select to adjust the horizontal position of the picture. Allows you to move the picture left and right in the window. Press ◀ or ▶ and press ⊕ to choose a correction between +50 and -50. | |
| 🔧 Horizontal Center | The variable range depends on the signal. | |
| Vertical Center | Select to adjust the vertical position of the picture. Allows you to move the picture up and down in the window. Press ◀ or ▶ and press ⊕ to choose a correction between +50 and -50. | |
| 🔧 Vertical Center | The variable range depends on the signal. | |

Accessing the Channel Settings

1. Press WEGA GATE..... 
2. Select Settings..... 
3. Highlight..... 
4. Press to select..... 




To highlight an option and to change settings, press **↑ ↓ ← →**.


Press **⏏** to confirm the selection.

To exit the Channel, press **WEGA GATE**.

Selecting Channel Options

 Channels that you set to Hidden can only be accessed with the 0-9 buttons.

The Channel settings include the following options:

| Option | Description |
|----------------------|---|
| Favorite Channels | Lets you set up a list of your favorite channels. For details, see “Using Favorites in WEGA GATE” on page 57. |
| Digital Channels Add | Select to add digital channels. |
| Auto Program | Automatically sets up the channel list on the TV for all receivable channels for the current input (VHF/UHF or CABLE). Select to start the Auto Program.  Auto Program may take up to 20 to 50 minutes to complete. A progress bar will display the approximate progress of the Auto Program and Digital Channels/Add sequences. |
| Show/Hide Channels | Allows you to show or hide channels that appear in the Program Guide and when you use the CH+/- buttons to channel surf. Channels that are set to Hidden do not appear in the Program Guide or when you use the CH+/- buttons. 1 Press ↑ or ↓ to highlight the channel that you want to show or hide. To move between the Major and Digital subchannel lists, press ← or → . 2 To change a channel’s setting to Shown or Hidden, press ⏏ . 3 To show or hide more channels, repeat steps 1 and 2. |

| Option | Description |
|--------|--|
| ✎ | If you select to hide or show a major digital channel, all the sub-channels are automatically hidden or shown. To show or hide an individual sub-channel within a digital channel, you must individually select that sub-channel to show or hide. |
| ✎ | If you hide all sub-channels of a major digital channel, that digital channel is automatically set to Hidden. |

- Label Channels** Allows you to assign labels (such as station call letters) to channel numbers.
- 1** Press **▲** or **▼** to scroll through the channel numbers. Then press **⊕** to select the channel number that you want to assign a label.
 - 2** Press **▲** or **▼** to scroll through the label characters (A-Z, 0-9, etc.). Then press **⊕** to select the highlighted character.
Repeat to add characters to the label.
 - 3** Press **◀** to return to the Channel setting, or press **WEGA GATE** to exit the settings.



Accessing the Parental Lock Settings

1. Press WEGA GATE.....




2. Select Settings.....



3. Highlight.....



4. Press to select.....



To highlight an option and to change settings, press **↑ ↓ ← →**.

Press **⊕** to confirm the selection.

To exit the Parental Lock, press **WEGA GATE**.

The Parental setting allows you to set up the TV to block programs according to their content and rating levels.





You need your password for any future access to the Parental Lock settings. If you have lost your password, see “Lost password” on page 93.

Selecting Parental Lock Options

The Parental Lock settings include the following options:

| Option | Description | | | | | | | | | | |
|--|--|-----|---|-------|---|-------|---|----------|---|--------|---|
| Parental Lock <i>Turn ratings on/off and select a rating system</i> | <table border="0"> <tr> <td>Off</td> <td>Turn Parental Lock off. No programs are blocked from viewing.</td> </tr> <tr> <td>Child</td> <td>Maximum ratings permitted are: U.S.: TV-Y, TV-G, G Canada: C, G, TV-Y</td> </tr> <tr> <td>Youth</td> <td>Maximum ratings permitted are: U.S.: TV-PG, PG Canada: C8+, PG, 8 ans+, TV-PG</td> </tr> <tr> <td>Y. Adult</td> <td>Maximum ratings permitted are: U.S.: TV-14, PG-13 Canada: 14+, 13 ans+, TV-14</td> </tr> <tr> <td>Custom</td> <td>Select to set ratings manually. U.S.: See page 76 for details. Canada: See page 77 for details.</td> </tr> </table> | Off | Turn Parental Lock off. No programs are blocked from viewing. | Child | Maximum ratings permitted are: U.S.: TV-Y, TV-G, G Canada: C, G, TV-Y | Youth | Maximum ratings permitted are: U.S.: TV-PG, PG Canada: C8+, PG, 8 ans+, TV-PG | Y. Adult | Maximum ratings permitted are: U.S.: TV-14, PG-13 Canada: 14+, 13 ans+, TV-14 | Custom | Select to set ratings manually. U.S.: See page 76 for details. Canada: See page 77 for details. |
| Off | Turn Parental Lock off. No programs are blocked from viewing. | | | | | | | | | | |
| Child | Maximum ratings permitted are: U.S.: TV-Y, TV-G, G Canada: C, G, TV-Y | | | | | | | | | | |
| Youth | Maximum ratings permitted are: U.S.: TV-PG, PG Canada: C8+, PG, 8 ans+, TV-PG | | | | | | | | | | |
| Y. Adult | Maximum ratings permitted are: U.S.: TV-14, PG-13 Canada: 14+, 13 ans+, TV-14 | | | | | | | | | | |
| Custom | Select to set ratings manually. U.S.: See page 76 for details. Canada: See page 77 for details. | | | | | | | | | | |

 If you are not familiar with the Parental Guideline rating system, you should select Child, Youth, or Y.Adult to help simplify the rating selection. To set more restrictive ratings, select Custom.


 For descriptions of Child, Youth, and Y.Adult ratings, see page 74.

| <i>Option</i> | <i>Description</i> |
|-----------------|---|
| Change Password | Select to change your password. |
| Select Country | U.S.A. Select to use U.S.A. ratings (see page 76). |
| | Canada Select to use Canadian ratings (see page 77). |

To deactivate the parental control feature

- Set Parental Lock to Off when in the Parental Lock setting.

To change the password

- 1** In the Parental Lock setting, use the arrow buttons to highlight Change Password, and press  to select it.
- 2** Enter a new four-digit password using the 0-9 buttons.
- 3** Confirm the new password by entering it again.
- 4** Press WEGA GATE to exit the setting screen.

Viewing Blocked Programs

You can view a blocked program by entering the password.

- 1** Press ENT when tuned to a blocked program.
- 2** Enter your password using the 0-9 buttons.
Parental Lock will be canceled temporarily until you turn your TV off.

Selecting Custom Rating Options


💡 To ensure maximum blocking capability, the age-based ratings should be blocked.

💡 If you select Block, be aware that the following programs may be blocked: news, sports, weather, emergency broadcasts, political programs, public service announcements, and religious programs.

US custom rating options

If you selected U.S.A. as the country of residence on page 75, the Custom Rating setting includes the following options. (If you selected Canada, see page 77.)

| Option | Description |
|---|--|
| Movie Rating | G All children and general audiences. |
| | PG Parental guidance suggested. |
| | PG-13 Parental guidance for children under 13. |
| | R Restricted viewing, parental guidance is suggested for children under 17. |
| | NC-17 and X No one 17 and under. |
| TV Rating <i>Block programs by their rating, content or both</i> | Age-Based Options |
| | TV-Y All children. |
| | TV-Y7 Directed to children age 7 and older. |
| | TV-G General audience. |
| | TV-PG Parental guidance suggested. |
| | TV-14 Parents strongly cautioned. |
| | TV-MA Mature audience only. |
| | Content-Based Options |
| | FV Fantasy violence. |
| | D Suggestive dialog. |
| | L Strong language. |
| | S Sexual situations. |
| | V Violence. |
| | Unrated <i>Block programs or movies that are broadcast without a rating</i> |
| Block Blocks all programs and movies that are broadcast without a rating. | |

 **The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG V (Violence) rating may contain moderate violence, while a TV-14 V (Violence) rating may contain more intense violence.**

Canadian custom rating options

If you selected **Canada** as the country of residence on page 75, the Custom Rating setting includes the following options. (If you selected **U.S.A.**, see page 76.)

| <i>Option</i> | <i>Description</i> | |
|----------------|---|------------------------------------|
| English Rating | C | All children. |
| | C8+ | Children 8 years and older. |
| | G | General programming. |
| | PG | Parental guidance. |
| | 14+ | Viewers 14 and older. |
| | 18+ | Adult programming. |
| French Rating | G | General programming. |
| | 8 ans+ | Not recommended for ages under 8. |
| | 13 ans+ | Not recommended for ages under 13. |
| | 16 ans+ | Not recommended for ages under 16. |
| | 18 ans+ | Programming restricted to adults. |
| U.S.A. Rating | See “TV Rating” on page 76 for details. | |

Accessing the Setup Settings

1. Press WEGA GATE.....




2. Select Settings.....



3. Highlight.....



4. Press to select.....



To highlight an option and to change settings, press **▲ ▼ ◀ ▶**.




Press **⊕** to confirm the selection.


To exit the Setup, press **WEGA GATE**.

Selecting Setup Options

The Setup settings include the following options:

| Option | Description | |
|----------------|---|--|
| Caption Vision | Allows you to select from four closed caption modes (for programs that are broadcast with closed captioning). | |
| | On | Caption Vision is turned on. |
| | Off | Caption Vision is turned off. |
| Program | Allows you to set basic and advanced Caption Vision options. See “Programming Caption Vision” on page 80. | |
| Info Banner | Set to On or Off. Select On to display the program name, time remaining and other information (if the broadcaster offers this service). Also displays when the channel is changed or the DISPLAY button is pressed. | |
| Game Mode | On | Select to optimize the lipsync when playing games. |
| | Off | Select to turn off the Game Mode. |

| Option | Description |
|--|---|
| Label Video Inputs | <p>Allows you to label the audio/video equipment you have connected to the TV so you can identify them when using TV/VIDEO. When in this setting:</p> <ol style="list-style-type: none"> 1 Press ▲ or ▼ to highlight an input to label, then press ⊕ to select it. 2 Use the arrow buttons to scroll through the labels. 3 Press ⊕ to select the equipment you connected to each of the input jacks on the back of your TV. <p>Select Skip if you do not have any equipment connected to a particular input.</p> |
| Video 1-6 | Video 1-6, VHS, DVD, Receiver, Satellite, Cable Box, 8mm, DTV, Game, LD, Beta, HD, DVR, Camcorder, Skip |
| Video 7 | Video 7, PC, DVD, HD, Game, Skip |
| <p> If you select Skip, your TV skips the selected connection when you press TV/VIDEO.</p> | |
| Language | Select to display all on-screen settings in your language of choice: English, Español, Français. |
| Video 2 (Component) | <p>Auto Select to switch automatically between the component video jacks (Y Pb/Cb Pr/CR, AUDIO L (MONO)/AUDIO R) and the composite video jacks (VIDEO, AUDIO L (MONO)/AUDIO R) on the left side of the TV (VIDEO/HD/DVD 2 IN) depending on the cable connection.</p> <p>Off Select to activate the composite video jacks (VIDEO/AUDIO L(MONO)/AUDIO R) on the left side of the TV.</p> |
| Menu Color | Enables you to select a specific color for the on-screen settings. |
| Image Shift | <p>Corrects the image on your TV.</p> <p>Before adjusting After adjusting</p> <div style="display: flex; justify-content: space-around;">   </div> <p>Auto (Factory setting) Automatically corrects double images.</p> <p>Level 1-4 Select a level from 1-4 to align the images and improve the picture.</p> |

 If you use the composite connection when Video 2 (Component) is set to Auto, do not connect the component cable at the same time. Otherwise select Off.

(Continued)

| Option | Description |
|---------------|--|
| High Altitude | Select On to use the TV at an altitude of 5,000 feet (1,500 m) or higher. Select Off to use the TV at normal altitude. |
| CineMotion | Select Auto to optimize the screen display automatically detecting film content and applying a reverse 3-2 pulldown process. Moving picture will appear clearer and more natural looking. Select Off to disable the detection. |

Programming Caption Vision


If you selected the Program option under Caption Vision (see page 78), you can change the following settings:


| Option | Description |
|-------------------|--|
| Basic | Allows you to select basic analog (EIA-608) closed caption options. |
| | CC1, CC2, CC3, CC4 Displays a printed version of the dialog or sound effects of a program. (Should be set to CC1 for most programs.) |
| | Text1, Text2, Text3, Text4 Displays network/station information presented using either half or the whole screen (if available). |
| Digital CC | Allows you to set digital closed captioning to Basic (digital EIA-608) or Advanced (digital EIA-708). |
| Advanced | Allows you to select advanced digital (EIA-708) closed caption options. Select from the available options. |
| Advanced Settings | Allows you to make additional settings for digital (EIA-708) closed caption options. Select from As Broadcast , Small Text , Large Text and Custom . |
| | Custom Allows you to customize the following settings: |
| | Character Size Small, Standard, Large |
| | Character Style Style 1-7 |
| | Character Color Color 1-8 |
| | Character Opacity Solid, Translucent |
| | Edge Color Color 1-8 |
| | Edge Type None, Raised, Depressed, Outline, Left Shadow, Right Shadow |
| | Background Color None, Color 1-8 |
| | Background Opacity Solid, Translucent |
| | Window Color None, Color 1-8 |
| | Window Opacity Solid, Translucent |

Selecting PC Setup Options

To display the PC screen:

Press TV/VIDEO repeatedly on the remote control until VIDEO 7 (PC) appears.



 You can change the settings for the PC input while the TV is displaying the PC screen.

The PC Input Setup setting includes the following options:

| Option | Description |
|------------------|--|
| Power Management | On Select to automatically switch to the Power Saving mode when there is no signal input for 10 minutes. |
| | Off Select to turn off Power Management. |
| Language | Select to display all on-screen settings in your language of choice: English, Español, Français. |
| Menu Color | Enables you to select a specific color for the on-screen settings from Original, Gray, Red, Green and Purple. |
| Image Shift | Auto (Factory setting) Automatically corrects double images. |
| | Level 1-4 Select a level from 1-4 to align the images and improve the picture. |
| High Altitude | Select On to use the TV at an altitude of 5,000 feet (1,500 m) or higher. Select Off to use the TV at normal altitude. |





Using the Settings

PC Input Signal Compatibility Chart

| Resolution | | | | Horizontal frequency (kHz) | Vertical frequency (Hz) | VESA standard |
|------------|------------------|----------|-----------------|----------------------------|-------------------------|---------------|
| Signals | Horizontal (Dot) | x | Vertical (Line) | | | |
| VGA | 640 | x | 480 | 31.5 | 60 | —* |
| | 640 | x | 480 | 37.5 | 75 | ✓ |
| | 640 | x | 480 | 43.3 | 85 | ✓ |
| | 720 | x | 400 | 31.5 | 70 | —* |
| SVGA | 800 | x | 600 | 35.2 | 56 | ✓ |
| | 800 | x | 600 | 37.9 | 60 | ✓ |
| | 800 | x | 600 | 46.9 | 75 | ✓ |
| | 800 | x | 600 | 48.1 | 72 | ✓ |
| XGA** | 1024 | x | 768 | 48.4 | 60 | ✓ |
| | 1024 | x | 768 | 56.5 | 70 | ✓ |
| | 1024 | x | 768 | 60 | 75 | ✓ |
| WXGA** | 1280 | x | 768 | 47.4 | 60 | ✓ |
| | 1280 | x | 768 | 47.8 | 60 | ✓ |

*: Corresponding to the VGA signal

** : These signals do not support Normal display mode.

-  **This TV does not support Sync on Green or Composite Sync.**
-  **If a signal other than in the above chart is input, it may not be displayed properly or may not be displayed as you set.**
-  **Using the Vertical frequency (Hz) of the personal computer at 60 is recommended.**
-  **Noise may be detected under certain conditions. If unsupported signals are used, you will see the message, “Unsupported Signal”.**

Accessing the Applications Settings

1. Press WEGA GATE.....




2. Select Settings.....



3. Highlight.....



4. Press to select.....



To highlight an option and to change settings, press \uparrow \downarrow \leftarrow \rightarrow .

Press \oplus to confirm the selection.

To exit the Applications, press WEGA GATE .

Selecting Applications Options

The Applications settings include the following options:

| Option | Description |
|--------------------|--|
| Clock/Timers | Select to set the clock and to program your TV to turn on and off at two scheduled viewing times. Once the options are set, TIMER LED lights up in red. |
| Sleep | Allows you to select the amount of time (Off, 15 minutes, 30 minutes, 45 minutes, 60 minutes or 90 minutes) that you want the TV to remain on before shutting off automatically. |
| Timer 1 Timer 2 | You can use the Timers to program the TV to turn on and off and tune to a specific channel at two scheduled viewing times. |

Timer 1 and Timer 2 cannot be set until you set the Current Time.

1 Press \uparrow or \downarrow to highlight Timer 1 or Timer 2. To set the timer, press \rightarrow .

To go directly to programming Timer 1 or 2, press \oplus instead of pressing \rightarrow .

(Continued)

| <i>Option</i> | <i>Description</i> |
|---------------------|---|
| | <p>2 Press ▲ or ▼ to highlight one of the following options, then press ⊕.</p> <p>Program Select to set the Timer by day, time, duration, and channel.</p> <p>Off Select to turn off the Timer. (Your previous settings are saved.)</p> |
| | <p>3 If you selected Program in step 2, press ▲ and ▼ to set the day(s), hour, minute, AM/PM, duration, and channel number. Press ⊕ or press ▶ to confirm each setting and move to the next setting.</p> <p>Press ◀ to go back to the previous setting.</p> |
| | <p>4 Press WEGA GATE to exit the setting screen. An LED on the front panel will light, indicating the Timer has been set.</p> |
| Current Time | You can set the current time. |
| | <p>1 Press ⊕ to select Current Time.</p> <p>2 Press ▲ and ▼ to set the current time (day, hour, minute, and AM/PM). Press ⊕ (or press ▶) to confirm each setting and move to the next setting. Press ◀ to go back the previous setting.</p> <p>3 Press WEGA GATE to exit the setting screen.</p> |
| Diagnostics | Display diagnostics information about the TV. This can be useful in providing information to an authorized technician or repair person. |
| CableCARD | This list of selectable CableCARD options will vary, depending on your cable service provider. |

Other Information

Overview

This chapter includes the following topics:

| <i>Topic</i> | <i>Page</i> |
|----------------------|-------------|
| Contacting Sony | 85 |
| Replacing the Lamp | 86 |
| Troubleshooting | 90 |
| Specifications | 94 |
| Optional accessories | 95 |
| Index | 96 |

Contacting Sony

If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Customer Information Services Center.

For US residents: 1-800-222-SONY (7669)

or visit: <http://www.sonystyle.com/tv/>

For Canadian residents: 1-877-899-SONY (7669)

or visit: <http://www.sonystyle.ca/tv/>

Before calling Sony customer support, please write down the model and serial numbers of your TV. You'll find this information on the front cover of this manual.

Replacing the Lamp

The projection lamp, which illuminates the picture, has a limited life.

If the screen becomes dark, the color looks unusual, or the LAMP indicator on the front of the TV flashes, it is time to replace the lamp with a new one (not supplied).


 **WARNING**


Electric appliances can cause fire or high temperature, resulting in injury or death. Be sure to follow the instructions below.

- Use a Sony XL-2400 replacement lamp (not supplied) for replacement. Use of any other lamp may damage the TV.
- Do not remove the lamp for any purpose other than replacement. Doing so may cause injury or fire.
- Do not put flammable materials and metal objects inside the lamp receptacle of the TV after removing the lamp. Doing so may cause fire or electrical shock. Do not touch the lamp receptacle once the lamp has been removed.
- When the lamp eventually burns out, you may hear a noticeable pop sound. This is normal and it is inherent to this type of lamp.
- In rare instances, the bulb may pop inside the lamp unit, but the lamp unit is designed to contain all of the broken glass pieces inside the lamp unit.
- The lamps contain mercury. For proper disposal of the used lamps, follow and observe the local ordinances. See page 89.


How to Replace the Lamp

- 1** Turn off the power on the main unit. Wait several minutes, then unplug the power cord.
(The cooling fan will continue to operate for about two minutes after turning the power off.)
- 2** Wait at least 30 minutes after unplugging the power cord to allow the lamp to cool down before replacing it. To avoid being burned, do not touch the lamp receptacle once the lamp has been removed.
- 3** Take the new lamp out of the box.
Do not touch the glass portion of the new lamp.


 **Do not shake the lamp. Vibration can damage the lamp or shorten its life.**

 **Avoid touching the front glass of a new lamp or the glass of the lamp receptacle. This may reduce picture quality or lamp life.**


- 4** Remove the outside lamp cover.





- 5** Remove the lamp door.
Turn the knob counterclockwise to OPEN and pull out the cover.




- 6** Pull out the lamp.
Hook a finger through the loop of the lamp handle and pull the handle upwards. Then pull the lamp straight out.




-  **The lamp is very hot immediately after use. Never touch the glass portion of the lamp or the surrounding parts.**
-  **After the used lamp has cooled, place it into the empty box of the replacement lamp. Never put the used lamp into a plastic bag.**


(Continued)

- 7** Put the new lamp into its place.
Mount the new lamp securely. Failure to do so may cause a fire or the screen to go dark.





 **If the lamp is not securely reattached, the self-diagnostic function may be triggered and the POWER/STANDBY indicator flashes three times (see page 12).**


- 8** Reattach the lamp door.
Turn the knob back to CLOSE and secure the cover.



- 9** Put the outside lamp cover back in its place.



 **Consult your Sony dealer for a Sony XL-2400 replacement lamp.**

 **Take great care when replacing the lamp or plugging in/unplugging the connecting cords. Rough handling may cause the TV to fall, damaging the TV, the TV stand and the floor.**

The used lamp

This product contains mercury. Disposal of this product may be regulated if sold in the United States. For disposal or recycling information, please contact your local authorities or the Electronics Industries Alliance (<http://www.eiae.org>).

- Do not leave the used lamp near flammable materials or within the reach of children.
- Do not pour water onto the used lamp or put any object inside the lamp. Doing so may cause the lamp to burst.

**For replacement lamp information visit:
U. S. residents: <http://www.sonystyle.com/tv/>
Canadian residents: <http://www.sonystyle.ca/tv/>**

Troubleshooting

Remote Control

| Problem | Possible Remedies |
|--|---|
| Remote control does not operate | <ul style="list-style-type: none"><input type="checkbox"/> The batteries could be weak. Replace the batteries.<input type="checkbox"/> Check the orientation of the batteries.<input type="checkbox"/> Press TV (FUNCTION) once, and the TV indicator lights up. You may have inadvertently pressed SAT/CABLE (FUNCTION), which changes the remote control to SAT or CABLE mode.<input type="checkbox"/> Make sure this unit's power cord is connected securely to the wall outlet.<input type="checkbox"/> Install the unit at least 3-4 feet away from fluorescent lights.<input type="checkbox"/> If the "High Temperature Warning!" message appears, turn off the TV and wait until the TV's projection lamp cools down (approximately 5 minutes). If the remote control still does not work, make sure to dust the ventilation slots on the rear of the TV and the cooling fan to provide adequate ventilation around the TV. |
| Cannot change channels with the remote control | <ul style="list-style-type: none"><input type="checkbox"/> If you are using the TV to change channels, first press TV (FUNCTION) once, and the TV indicator lights up.<input type="checkbox"/> If you are using another device to change channels, be sure you have not inadvertently switched your TV from the channel 3 or 4 setting.<input type="checkbox"/> If you are using another device to change channels, be sure to press FUNCTION for that device. For example, if you are using your cable box to change channels, be sure to press SAT/CABLE (FUNCTION) once, and the SAT/CABLE indicator lights up. |
| Remote control does not operate non-Sony video equipment | <ul style="list-style-type: none"><input type="checkbox"/> If you replaced the batteries to the remote recently, the code numbers for the video equipment may need to be reset.<input type="checkbox"/> There may be more than one code for the equipment that you are attempting to operate.<input type="checkbox"/> There is a possibility that some non-Sony equipment cannot be operated by your Sony TV remote. You may need to use the equipment's original remote control. |

CableCARD Device

| Problem | Possible Remedies |
|---|--|
| Problems using CableCARD device or CableCARD services | <ul style="list-style-type: none"><input type="checkbox"/> Check that the CableCARD is inserted properly (see pages 30-31).<input type="checkbox"/> The CableCARD device must be activated by your local cable TV provider before you can receive digital cable TV services. See the activation instructions on pages 30-31.<input type="checkbox"/> Check the Diagnostics and CableCARD setting options (see page 84). (This can be useful in providing information to an authorized technician or repair person.)<input type="checkbox"/> Contact your cable TV provider. |

Video

| Problem | Possible Remedies |
|---|--|
| No picture (screen not lit), no sound | <ul style="list-style-type: none"> <input type="checkbox"/> If your TV does not turn on and a red light keeps flashing, your TV may need service. Call your local Sony Service Center. <input type="checkbox"/> Make sure the power cord is plugged in. <input type="checkbox"/> Press POWER on the front of the TV. <input type="checkbox"/> Press TV/VIDEO to cycle through the connected video sources. <input type="checkbox"/> Try another channel; it could be station trouble. |
| Dark, poor or no picture (screen lit), good sound | <ul style="list-style-type: none"> <input type="checkbox"/> Adjust the Picture Mode option in the Video setting (see page 63). <input type="checkbox"/> Adjust the Brightness option in the Video setting (see page 63). <input type="checkbox"/> Check the antenna/cable connections. |
| No color/dark picture/color is not correct | <ul style="list-style-type: none"> <input type="checkbox"/> Adjust the Color option in the Video setting (see page 63). |
| Only snow and noise appear on the screen | <ul style="list-style-type: none"> <input type="checkbox"/> Check the antenna/cable connections. <input type="checkbox"/> Try another channel; it could be station trouble. <input type="checkbox"/> Press ANT to change the input mode (see page 44). |
| Dotted lines or stripes | <ul style="list-style-type: none"> <input type="checkbox"/> Adjust the antenna. <input type="checkbox"/> Move the TV away from noise sources such as cars, neon signs, or hair dryers. |
| Double images | <ul style="list-style-type: none"> <input type="checkbox"/> Using a highly directional outdoor antenna or a cable may solve the problem. <input type="checkbox"/> Set Image Shift to an appropriate value. The default setting is Auto. If doubled images appear with Auto, select the best value from 1 to 4 (see page 79). |
| "Black box" on screen | <ul style="list-style-type: none"> <input type="checkbox"/> You have selected a text option in the Setup setting and no text is available. (See page 78 to reset Setup selections.) To turn off this feature, set the Caption Vision option to Off. If you were trying to select closed captioning, select CC1 instead of Text 1-4. |
| Black bands appear at the top and bottom of the screen | <ul style="list-style-type: none"> <input type="checkbox"/> Some wide-screen programs are filmed in aspect ratios that are greater than 16:9 (this is especially common with theatrical releases). Your TV will show these programs with black bands at the top and bottom of the screen. For more details, check the documentation that came with your DVD (or contact your program provider). |
| Certain programs on DVD or other digital sources display a loss of detail, especially during fast-motion or dark scenes | <ul style="list-style-type: none"> <input type="checkbox"/> The compression used by certain digital broadcasts and DVDs may cause your TV's screen to display less detail than usual, or cause artifacts (small blocks or dots, pixelations) to appear on your screen. This is due to your TV's large screen and ability to show very fine detail, and is normal for certain digitally recorded programs. Adjust the reality/clarity in the DRC Palette setting (see page 64) to optimize the picture while viewing these sources. |
| "Iris Unit error" appears while Advanced Iris is active | <ul style="list-style-type: none"> <input type="checkbox"/> The Iris Control may have a problem. Call your local Sony Service Center. |

Audio

| Problem | Possible Remedies |
|--|--|
| Good picture, no sound | <ul style="list-style-type: none"><input type="checkbox"/> Press MUTING so that Muting disappears from the screen (see page 44).<input type="checkbox"/> Make sure the Speaker option is set to On in the Audio setting (see page 67).<input type="checkbox"/> Make sure the MTS option is set to Stereo or Mono (see page 67).<input type="checkbox"/> When the HDMI IN input is in use, surround sound, such as AC-3 and DTS, cannot be input. Change the sound setting for the external input device to Linear PCM. |
| Audio noise | <ul style="list-style-type: none"><input type="checkbox"/> Communication problems may occur if infrared communication equipment (e.g., infrared cordless headphones) is used near the TV. Use headphones other than infrared cordless headphones. Also, if you use infrared communication equipment other than infrared cordless headphones, move the infrared transceiver away from the TV until the noise is eliminated, or move the transmitter and receiver of the infrared communication equipment closer together. |
| Cannot gain enough volume when using a cable box | <ul style="list-style-type: none"><input type="checkbox"/> Increase the volume of the cable box using the cable box's remote control. Then press TV(FUNCTION) once (the TV indicator lights up) and adjust the TV's volume. |
| Sound seems weak or insufficient | <ul style="list-style-type: none"><input type="checkbox"/> The TV's audio might be set to Auto SAP or Mono, when it might be better set to Stereo. In the Audio setting (see page 67), set the MTS setting to Stereo. If already set to Stereo, switch to Mono (which may reduce background noise during weak stereo broadcasts). |
| Cannot raise the volume on external speakers | <ul style="list-style-type: none"><input type="checkbox"/> If the Speaker option is set to Off and the Audio Out option is set to Fixed (in order to output the sound to your audio system), use your audio receiver to adjust the sound (see page 67). Or, to use the TV remote control, set the Audio Out option to Variable.<input type="checkbox"/> To turn on the TV speakers, set the Speaker option to On (see page 67). |

Channels


| Problem | Possible Remedies |
|---|--|
| Cannot receive upper channels (UHF) when using an antenna | <ul style="list-style-type: none"><input type="checkbox"/> Press ANT to select the VHF/UHF input (see page 44).<input type="checkbox"/> Use Auto Program in the Channel setting to add receivable channels that are not presently in the TV's memory (see page 72). |
| Cannot receive any channels when using cable TV | <ul style="list-style-type: none"><input type="checkbox"/> Use Auto Program in the Channel setting to add receivable channels that are not presently in the TV's memory (see page 72).<input type="checkbox"/> Press ANT to select the CABLE input (see page 44). |
| Cannot receive or select channels | <ul style="list-style-type: none"><input type="checkbox"/> Use Auto Program in the Channel setting to add receivable channels that are not presently in TV memory (see page 72). |
| Some digital cable channels are not being displayed | <ul style="list-style-type: none"><input type="checkbox"/> Certain cable companies have limitations on the broadcast of digital cable channels. Check with your cable company for more information.<input type="checkbox"/> The digital cable channel may be set to Hidden in the Channel setting (see page 72). |

General

| Problem | Possible Remedies |
|--|--|
| How to reset TV to factory settings | <input type="checkbox"/> Turn on the TV. While holding down the ↑ button on the remote control, press the POWER button on the TV. (The TV will turn itself off, then back on again.) Release the ↑ button. WARNING: The Factory Reset will clear all of your customized settings including Parental Lock setting. |
| How to restore Video settings to factory settings | <input type="checkbox"/> Select Reset setting option while in the Video setting (see page 66). |
| How to restore Audio settings to factory settings | <input type="checkbox"/> Select Reset setting option while in the Audio setting (see page 66). |
| Cannot cycle through the other video equipment connected to the TV | <input type="checkbox"/> Be sure the Label Video Inputs option is not set to Skip (see page 79). |
| Cannot operate the setting | <input type="checkbox"/> If a setting option appears in gray, this indicates that the setting option is not available. |
| Lost password | <input type="checkbox"/> On the password screen (see page 74), enter the following master password: 4357. The master password clears your previous password; it cannot be used to temporarily unblock channels. |
| TIMER LED on front panel is lit | <input type="checkbox"/> When lit, indicates that the timer is set (see page 83). When the timer is set, this LED will remain lit even when the TV is turned off. |
| LAMP LED blinks in red | <input type="checkbox"/> Replace the lamp (see page 86). |
| Digital cable box does not work | <input type="checkbox"/> If you are connecting a VCR and digital cable box using a splitter, as described on page 35, you must use a special bi-directional splitter that is designed to work with your digital cable box. Contact your cable provider for details. |
| Cannot record digital channels to VCR | <input type="checkbox"/> Only analog channels can be recorded to your VCR. |
| TV cabinet creaks | <input type="checkbox"/> When the TV is in use, there is a natural rise in temperature, causing the cabinet to expand or contract and may be accompanied by a slight creaking noise. This is not a malfunction. |
| A slight creaking noise occurs from the bottom part of the TV | <input type="checkbox"/> Advanced Iris applies a mechanical iris system. When Advanced Iris is set, a natural creaking noise occurs due to the basic structure of the optical unit. The creaking sound is an inherent nature of this system and is not a defect. |
| The cooling fan is loud | <input type="checkbox"/> If the TV is used at high altitudes and High Altitude is set to On , the cooling fan runs faster and its sound becomes louder. If the TV is not used at high altitudes, set High Altitude to Off (see page 81). |
| "High Temperature Warning!" message appears | <input type="checkbox"/> Make sure to remove dust from the ventilation slots on the rear and both sides of the TV. In addition, make sure that there are no obstacles in front of the ventilation slots. If the message still appears after the dust or obstacles are removed, the TV may need servicing. Call your local Sony Service Center. |
| The TV does not turn on | <input type="checkbox"/> The TV cools down its projection lamp when the power is turned off. It takes up to two minutes for the picture to come back after the TV is turned on again. Wait for a while until the picture comes back. |

Other Information


Specifications

| | | |
|---|---|---|
| Projection System | 3 LCD Panels, 1 lens projection system | |
| LCD Panel | 0.73 inch TFT LCD panel (1,280 × 720 pixels) | |
| Projection Lens | High Performance, large diameter hybrid lens F2.4 | |
| Antenna | 75-ohm external terminal for VHF/UHF | |
| Lamp | 100W, XL-2400 | |
| Television System | NTSC | American TV Standard |
| | ATSC (8VSB terrestrial) | ATSC compliant 8VSB |
| | QAM on cable | ANSI/SCTE 07 2000 |
| Visible Screen Size (Picture measured diagonally) | KDF-E42A10: | 42 inches |
| | KDF-E50A10: | 50 inches |
| Channel Coverage | Terrestrial (analog) | 2-69 |
| | Cable TV (analog) | 1-125 |
| | Terrestrial (digital) | 2-69 |
| | Cable TV (digital) | 1-135 |
| Number of Inputs/Outputs | | |
| HDMI IN | Video | 1080i, 720p, 480p, 480i |
| | Audio | Two channel linear PCM 32, 44.1 and 48 kHz, 16, 20 and 24 bit |
| Video (IN) | 3 total (1 on side panel) | 1 Vp-p, 75 ohms unbalanced, sync negative |
| S Video (IN) | 1 | Y: 1 Vp-p, 75 ohms unbalanced, sync negative |
| | | C: 0.286 Vp-p (Burst signal), 75 ohms |
| Audio (IN) | 5 total (1 on side panel) | 500 mVrms (100% modulation) |
| | | Impedance: 47 kilohms |
| Component Video Input | 2 (Y Pb/Cb Pr/Cr) | Y: 1 Vp-p, 75 ohms unbalanced, sync negative |
| | | Pb/Cb: 0.7 Vp-p, 75 ohms |
| | | Pr/Cr: 0.7 Vp-p, 75 ohms |
| AUDIO (VAR/FIX) OUT | 1 | 500 mVrms at the maximum volume setting (Variable) |
| | | 500 mVrms (Fixed) |
| | | Impedance (output): 2 kilohms |
|  AUDIO OUT jacks are operable only when the TV's Speaker is set to Off. | | |
| RF Inputs | 2 | |
| PC Input | 1 | |
| Digital Audio Optical Output (PCM/Dolby Digital) | 1 | Optical Rectangular (1) |
| CableCARD Slot | PCMCIA Type I/II | |
| Speaker output | 12 W + 12 W | |
| Power requirement | 120 V, 60 Hz | |
| Power consumption | In use: 210 W | |
| | In standby: Less than 17 W | |

| | |
|---------------------------|---|
| Dimensions (W/H/D) | KDF-E42A10: 999 × 722 × 357 mm (39 ³ / ₈ × 28 ¹ / ₂ × 14 ¹ / ₈ inches) |
| | KDF-E50A10: 1184 × 827 × 408 mm (46 ⁵ / ₈ × 32 ⁵ / ₈ × 16 ¹ / ₈ inches) |
| Mass | KDF-E42A10: 28 kg (61 lb. 12 oz.) |
| | KDF-E50A10: 33 kg (72 lb. 13 oz.) |
| Supplied Accessories | |
| Remote Control | RM-YD003 |
| AA (R6) Batteries | 2 supplied for remote control |
| Operating Instructions | 1 |
| Quick Setup Guide | 1 |
| Warranty Card | 1 |
| Product Registration Card | 1 |

Optional accessories:

- HDMI cable
- HDMI-to-DVI cable
- Component video cable
- S VIDEO cable
- A/V cable
- Audio cable
- Optical cable
- TV Stand : (SU-RG11S for KDF-E42A10, SU-RG11M for KDF-E50A10)
- Theatre Stand System: RHT-G2000
- Lamp : XL-2400

 **The availability of optional accessories depends on stock.**

Design and specifications are subject to change without notice.
Non-metric weights and measures are approximate.

Index

- 0-9 buttons 44
- 4:3 Default 70
- 5.1 Channel DVD using with remote control 50

A

- A/V Sync 67
- About Using CableCARD Device 30
- AC IN 18
- Adding channels to the channel list 72
- Adjusting audio, Steady Sound 66
- Advanced Iris 63
- Advanced Video 65
- Alternate Audio 52
- Alternate Video 52
- ANT button 44
- Applications Settings 62, 83
- Audio Out 67, 68
- AUDIO OUT jack, described 18
- Audio receiver, connecting 42
- Audio settings 61, 66
- Auto Adjustment 71
- Auto Program 72

B

- Balance, adjusting 66, 68
- Bass, adjusting 66, 68
- Batteries, inserting in remote 43
- BBE 66
- Brightness, adjusting 63, 65

C

- Cable
 - connecting with VCR 34
 - using with remote control 49
- Cable Box
 - connecting with VCR 35
- CableCARD device 30, 84
- CableCARD slot 17

- Camcorder connection 41
- Caption Vision 78
 - programming 80
- Change Password 75
- CHANNEL +/- button 15
- Channel settings 62, 72
- Channel Show/Hide 72
- Channels
 - Auto Program 72
 - creating labels 73
- CineMotion 9, 80
- Clear White 65
- Clock/Timers 83
- Closed caption modes 78
- Color Temp., adjusting 64, 65
- Color, adjusting 63
- Connecting
 - Audio receiver 42
 - Cable box 23–24
 - Camcorder 41
 - DVD player 38–39
 - Personal Computer 40
 - Satellite receiver 25
 - VCR 34–37

D

- Diagnostics 84
- DIGITAL AUDIO (OPTICAL) OUT 18
- Digital Channels 72
- Digital subchannels 52
- Display Area 70
- DISPLAY button 45
- Display Mode 65
- Display, turning off 45
- DRC Mode 64
- DRC Palette 64
- DVD player
 - using with remote control 49
 - with A/V connectors, connecting 39
 - with component video connectors, connecting 38

E

- Effect 66, 68
- English Rating 77
- ENT button 44
- External Inputs, WEGA GATE 56, 59

F

- Favorite Channels
 - setting up 72
- Favorites, WEGA GATE 56, 57
- FREEZE button 45, 54
- French Rating 77
- FUNCTION button 44

G

- Game Picture 69
- Gamma 65
- GUIDE button 51
- Guide menu 52

H

- HD/DVD IN jack (1080i/720p/480p/480i), described 16, 18
- HDMI IN jack, described 17
- High Altitude 80, 81
- High-Definition Multimedia Interface (HDMI) 10
- Horizontal Center 71
- Hue, adjusting 63

I

- Image Shift 79
- Infrared Receiver (IR) 15
- Inputs, labeling 79
- Iris 63, 65

J, K

- JUMP 54
- JUMP button 44

- L**
 Label
 Channels 73
 Label Video Inputs 79
 LAMP LED 15
 Lamp, replacing 86–89
 Language 79, 81
 Live Color 65
- M**
 MENU button 45, 49
 Menu Color 79, 81
 Movie Rating 76
 MTS 67
 MUTING button 44
- N**
 Noise Reduction 64
- O**
 Off, turning off the TV 15
 On, turning on the TV 15
- P, Q**
 Parental Control, described 9
 Parental Lock settings 62, 74
 Password, changing 75
 PC IN jack 17
 PC Input 65, 68, 71, 81
 Personal Computer
 connecting 40
 Phase 71
 Picture 63, 65
 PICTURE button 44
 Picture Mode
 Custom 63
 Standard 63
 Vivid 63
 Pitch 71
 POWER button 15
 Power Management 81
 POWER/STANDBY LED 15
 Problems, Troubleshooting 90–93
 Program Guide 52
 Program Options menu 52
- R**
 Ratings
 setting 76
 viewing blocked programs 75
 Remote control
 inserting batteries 43
 programming 47–48
 Removing channels from the
 channel list 72
 Removing the CableCARD 31
 Reset 63, 65, 66, 68
- S**
 S VIDEO jack, described 18
 Satellite receiver
 connecting 25
 Satellite receiver, using with
 remote control 49
 Screen settings 61, 69
 Select Country 75
 Settings
 Applications 62, 83
 Audio 61, 66
 Channel 62, 72
 Parental Lock 62, 74
 Screen 61, 69
 Setup 62, 78
 Video 61, 63
 Settings, WEGA GATE 56, 59
 Setup settings 62, 78
 Sharpness, adjusting 64
 Show/Hide Channels 72
 Sound Mode 66, 68
 Speaker 15, 67, 68
 Specifications 94–95
 Steady Sound
 adjusting 66
 described 10
 Support Belt 14
 Surround sound 66, 68
- T, U**
 Timer
 set current 84
 TIMER indicator 12
 TIMER LED 15
 Timer setting 83
 Treble, adjusting 66, 68
 Troubleshooting 90–93
- Turning on/off the TV 15
 TV FUNCTION button 44
 TV POWER button 45
 TV Rating 76
 TV/VIDEO button 15, 44
 U.S.A. Rating 77
 Unrated 76
- V**
 VCR
 using with remote control 49
 with cable box, connecting 35
 with cable, connecting 34
 Vertical Center 70, 71
 Vertical Size 70
 VHF/UHF jack, described 17
 Video 2 (Component) 79
 Video inputs, labeling 79
 Video settings 61, 63
 VIDEO/AUDIO (L/R) jacks,
 described 16, 18
 VISUAL SEARCH 45
 VOL +/- button 45
 VOLUME +/- button 15
 Volume Offset 66
- W, X, Y**
 WEGA GATE 9, 55
 WEGA GATE button 15
 Wide Mode 69, 71
 Wide Screen Mode, described 9



<http://www.sony.net/>

Printed in U.S.A.
